

Dival 700

Medium-low pressure gas regulator



Revision A - Edition 03/2023

**USE, MAINTENANCE
AND WARNING
MANUAL**

1 - INTRODUCTION

FOREWORD

All rights reserved. No part of this publication may be reproduced, distributed, translated into other languages or transmitted by any electronic or mechanical media, including photocopies, recording or any other storage and retrieval system, for any other purposes that are not exclusively the personal use of the buyer, without the express written permission of the Manufacturer.

The manufacturer is in no way responsible for the consequences of operations carried out in a manner not in accordance with the manual.

GENERAL REMARKS

All operating, maintenance instructions and recommendations described in this manual must be observed. In order to obtain the best performance and to keep the equipment in efficient condition, the manufacturer recommends that maintenance operations be carried out regularly.

It is of particular importance that the personnel responsible for the equipment be trained in its use, maintenance and application of the safety instructions and procedures indicated in this manual.

Revision: A

1.1 - REVISION HISTORY

| Revision index | Date | Revision contents |
|----------------|---------|-------------------|
| A | 03/2023 | First issue |
| | | |
| | | |

Tab. 1.1

INDEX

| | |
|---|-----------|
| 1 - INTRODUCTION | 3 |
| 1.1 - REVISION HISTORY..... | 5 |
| 2 - GENERAL INFORMATION | 11 |
| 2.1 - MANUFACTURER IDENTIFICATION | 11 |
| 2.2 - IDENTIFICATION OF THE PRODUCT | 11 |
| 2.3 - REGULATORY FRAMEWORK..... | 11 |
| 2.4 - WARRANTY | 11 |
| 2.5 - SYMBOLS USED IN THE MANUAL..... | 12 |
| 2.6 - ADDRESSEES, SUPPLY AND STORAGE OF THE MANUAL..... | 13 |
| 2.7 - LANGUAGE | 13 |
| 2.8 - APPLIED RATING PLATES | 14 |
| 2.8.1 - GLOSSARY FOR RATING PLATES..... | 15 |
| 2.9 - GLOSSARY OF MEASUREMENT UNITS..... | 16 |
| 2.10 - QUALIFIED PROFESSIONAL FIGURES..... | 17 |
| 3 - SAFETY | 19 |
| 3.1 - GENERAL SAFETY WARNINGS..... | 19 |
| 3.2 - PERSONAL PROTECTIVE EQUIPMENT..... | 20 |
| 3.3 - RESIDUAL RISKS | 21 |
| 3.3.1 - TABLE SHOWING RESIDUAL RISKS DUE TO PRESSURE | 22 |
| 3.3.2 - TABLE OF RESIDUAL RISKS FOR POTENTIALLY EXPLOSIVE ATMOSPHERES | 24 |
| 3.4 - OBLIGATIONS AND PROHIBITIONS | 26 |
| 3.5 - SAFETY PICTOGRAMS | 27 |
| 3.6 - NOISE LEVEL | 27 |

4 - DESCRIPTION AND OPERATION 29

| | |
|---|----|
| 4.1 - GENERAL DESCRIPTION | 29 |
| 4.1.1 - REGULATOR REACTION MODES..... | 30 |
| 4.2 - OPERATION..... | 30 |
| 4.3 - INTENDED USE | 32 |
| 4.3.1 - ENVISAGED USE | 32 |
| 4.3.2 - REASONABLY FORESEEABLE MISUSE | 32 |
| 4.3.3 - TYPES OF FLUIDS | 32 |
| 4.4 - TECHNICAL FEATURES/PERFORMANCE | 33 |
| 4.4.1 - VARIATION OF OUTLET PRESSURE AS INLET PRESSURE CHANGES BY 0.5 BAR..... | 34 |
| 4.4.2 - SPRING SETTING RANGE..... | 35 |
| 4.4.2.1 - INLET PRESSURE 1.7 BAR..... | 35 |
| 4.4.2.2 - INLET PRESSURE 3.4 BAR..... | 35 |
| 4.5 - POSSIBLE CONFIGURATIONS | 36 |
| 4.5.1 - CONTROL HEADS..... | 36 |
| 4.5.2 - ACCESSORIES..... | 36 |
| 4.5.3 - REGULATOR WITH MONITOR FUNCTION..... | 37 |
| 4.5.4 - SLAM-SHUT VALVE | 40 |
| 4.5.4.1 - LA INCORPORATED SLAM-SHUT VALVE..... | 41 |

5 - TRANSPORT AND HANDLING 43

| | |
|---|----|
| 5.1 - SPECIFIC WARNINGS FOR TRANSPORT AND HANDLING | 43 |
| 5.1.1 - PACKAGING AND FASTENERS USED FOR TRANSPORT | 44 |
| 5.2 - PHYSICAL CHARACTERISTICS OF THE EQUIPMENT | 46 |
| 5.2.1 - DIVAL 700..... | 46 |
| 5.2.2 - DIVAL 700 + LA..... | 47 |
| 5.3 - EQUIPMENT ANCHORING AND LIFTING METHOD..... | 48 |
| 5.3.1 - FORKLIFT HANDLING METHOD..... | 49 |
| 5.3.2 - CRANE HANDLING METHOD..... | 51 |
| 5.4 - PACKAGING REMOVAL..... | 52 |
| 5.4.1 - PACKAGING DISPOSAL | 52 |
| 5.5 - STORAGE AND ENVIRONMENTAL CONDITIONS | 53 |
| 5.5.1 - PRE-INSTALLATION WARNINGS AFTER PROLONGED STORAGE | 53 |

6 - INSTALLATION 55

| | |
|---|----|
| 6.1 - INSTALLATION PRE-REQUISITES..... | 55 |
| 6.1.1 - ALLOWED ENVIRONMENTAL CONDITIONS..... | 55 |
| 6.1.2 - CHECKS BEFORE INSTALLATION..... | 56 |
| 6.2 - SPECIFIC SAFETY INSTRUCTIONS FOR THE INSTALLATION STEP | 57 |
| 6.3 - GENERAL INFORMATION ON CONNECTIONS | 58 |
| 6.4 - REGULATOR INSTALLATION POSITIONS..... | 59 |
| 6.5 - INSTALLATION PROCEDURES | 60 |
| 6.5.1 - EQUIPMENT INSTALLATION PROCEDURES | 60 |
| 6.5.2 - CONNECTION OF THE SENSING LINES TO THE DOWNSTREAM PIPING..... | 60 |
| 6.6 - POST-INSTALLATION AND PRE-COMMISSIONING CHECKS | 63 |

7 - COMMISSIONING/MAINTENANCE EQUIPMENT..... 65

| | |
|--|----|
| 7.1 - LIST OF EQUIPMENT..... | 65 |
| 7.2 - EQUIPMENT NEEDED FOR THE DIFFERENT CONFIGURATIONS..... | 67 |

8 - COMMISSIONING 69

| | |
|--|----|
| 8.1 - GENERAL WARNINGS | 69 |
| 8.1.1 - SAFETY REQUIREMENTS FOR COMMISSIONING | 69 |
| 8.2 - PRELIMINARY PROCEDURES FOR COMMISSIONING | 70 |
| 8.3 - PROPER COMMISSIONING CHECK | 71 |
| 8.4 - CALIBRATION OF EQUIPMENT AND ACCESSORIES INSTALLED..... | 71 |
| 8.5 - REGULATOR COMMISSIONING PROCEDURE | 72 |
| 8.6 - COMMISSIONING PROCEDURE OF REGULATION LINE: DIVAL 700 REGULATOR + DIVAL 700 REGULATOR WITH IN LINE MONITOR FUNCTION | 74 |
| 8.6.1 - PRESSURISING WITH EXTERNAL SOURCE..... | 78 |
| 8.7 - COMMISSIONING PROCEDURE OF DIVAL 700 REGULATOR WITH LA SLAM-SHUT VALVE..... | 80 |
| 8.7.1 - INTERNAL TIGHTNESS CHECK OF LA SLAM-SHUT VALVE..... | 80 |
| 8.7.2 - COMMISSIONING OF THE DIVAL 700 REGULATOR WITH LA SLAM-SHUT VALVE..... | 81 |
| 8.7.3 - PROCEDURE FOR CALIBRATING THE PRESSURE SWITCH FOR THE LA INCORPORATED SLAM-SHUT VALVE..... | 84 |
| 8.8 - COMMISSIONING PROCEDURE OF REGULATION LINE: DIVAL 700 REGULATOR + DIVAL 700 REGULATOR WITH IN LINE MONITOR + LA SLAM-SHUT VALVE FUNCTION | 88 |
| 8.11 -DEVICE CALIBRATION..... | 92 |
| 8.11.1 - PRESSURE SWITCH CALIBRATION FOR THE LA SLAM-SHUT VALVE | 92 |

9 - MAINTENANCE AND FUNCTIONAL CHECKS..... 93

| | |
|--|-----|
| 9.1 - GENERAL WARNINGS | 93 |
| 9.2 - PERIODICALLY CHECKING AND INSPECTING THE EQUIPMENT FOR PROPER OPERATION..... | 95 |
| 9.3 - ROUTINE MAINTENANCE | 96 |
| 9.3.1 - GENERAL SAFETY WARNINGS..... | 96 |
| 9.3.2 - REPLACEMENT FREQUENCY FOR COMPONENTS SUBJECT TO WEAR | 97 |
| 9.4 - ROUTINE MAINTENANCE PROCEDURES..... | 99 |
| 9.4.1 - TIGHTENING TORQUES | 100 |
| 9.4.2 - REPLACING ELEMENTS SUBJECT TO WEAR AND ABRASION..... | 107 |
| 9.4.3 - REGULATOR MAINTENANCE PROCEDURE DIVAL 700..... | 108 |
| 9.4.4 - LA SLAM-SHUT VALVE | 120 |
| 9.4.6 - PROCEDURE FOR RECOMMISSIONING AFTER MAINTENANCE | 132 |

10 - TROUBLESHOOTING..... 133

| | |
|--|-----|
| 10.1 -GENERAL WARNINGS | 133 |
| 10.2 -OPERATOR QUALIFICATION SPECIFICATION..... | 134 |
| 10.3 -TROUBLESHOOTING PROCEDURES | 134 |
| 10.4 -TROUBLESHOOTING TABLES | 135 |
| 10.4.1 -TROUBLESHOOTING DIVAL 700 REGULATOR..... | 135 |
| 10.4.2 -LA SLAM-SHUT VALVE TROUBLESHOOTING..... | 135 |

11 - UNINSTALLATION AND DISPOSAL 137

| | |
|--|-----|
| 11.1 -GENERAL SAFETY WARNINGS..... | 137 |
| 11.2 -QUALIFICATION OF THE OPERATORS IN CHARGE..... | 137 |
| 11.3 -UNINSTALLATION..... | 137 |
| 11.4 -INFORMATION REQUIRED IN CASE OF RE-INSTALLATION..... | 137 |
| 11.5 -DISPOSAL INFORMATION..... | 138 |

12 - RECOMMENDED SPARE PARTS 139

| | |
|---------------------------------------|-----|
| 12.1 -GENERAL WARNINGS | 139 |
| 12.2 -HOW TO REQUEST SPARE PARTS..... | 139 |

13 - FLOW RATE TABLES..... 141

| | |
|------------------------------|-----|
| 13.1 -FLOW RATE TABLES | 141 |
|------------------------------|-----|

2 - GENERAL INFORMATION

2.1 - MANUFACTURER IDENTIFICATION

| | |
|---------------------|---|
| Manufacturer | PIETRO FIORENTINI S.P.A. |
| Address | Via Enrico Fermi, 8/10 36057 Arcugnano (VI) - ITALY Tel. +39 0444 968511 Fax +39 0444 960468 www.fiorentini.com sales@fiorentini.com |

Tab. 2.2

2.2 - IDENTIFICATION OF THE PRODUCT

| | |
|------------------|--------------------------------|
| Equipment | REGOLATORE PER MEDIA PRESSIONE |
| Model | DIVAL 700 |

Tab. 2.3

2.3 - REGULATORY FRAMEWORK

PIETRO FIORENTINI S.P.A., with registered offices in Arcugnano (Italy) - Via E. Fermi, 8/10, declares under its sole responsibility that the equipment of the DIVAL 700 series described in this manual is designed, manufactured, tested and checked in compliance with the requirements of EN 334 standard on gas pressure regulators.

The equipment complies with the requirements of Directive 2014/68/EU ("Pressure Equipment Directive" PED). The assessment procedure adopted is in accordance with module H1 as per Annex III of the Directive.

NOTICE!

The declaration of conformity in its original version is delivered together with the equipment and this operating and warning manual.

2.4 - WARRANTY

PIETRO FIORENTINI S.P.A. guarantees that the equipment was manufactured using the best materials, with high quality workmanship, and complies with the quality requirements, specifications and performance set out in the order.




The warranty shall be considered null and void and PIETRO FIORENTINI S.P.A. shall not be liable for any damage and/or malfunctions:

- due to any acts or omissions of the purchaser or end-user, or any of their carriers, employees, agents, or any third party or entity;
- in the event that the purchaser, or a third party, makes changes to the equipment supplied by PIETRO FIORENTINI S.P.A. without the prior written approval of the latter;
- in the event of failure by the purchaser to comply with the instructions contained in this manual, as provided by PIETRO FIORENTINI S.P.A.

NOTICE!

The warranty conditions are specified in the commercial contract.

2.5 - SYMBOLS USED IN THE MANUAL

| Symbol | Definition |
|---|--|
|  | Symbol used to identify important warnings for the safety of the operator and/or equipment. |
|  | Symbol used to identify information of particular importance in the instruction manual. The information may also concern the safety of the personnel involved in using the equipment. |
|  | Obligation to consult the instruction manual/booklet. Indicates a requirement for the personnel to refer to (and understand) the operating and warning instructions of the machine before working with or on it. |

Tab. 2.4

HAZARD!

Alerts to a hazard with a high level of risk, an imminent hazardous situation which, if not prevented, will result in death or severe damage.

WARNING!

Alerts to a hazard with a medium level of risk, a potentially hazardous situation which, if not prevented, may result in death or severe damage.

ATTENTION!

Alerts to a hazard with a low level of risk, a potentially hazardous situation which, if not prevented, could result in minor or moderate damage.

NOTICE!

Alerts to specific warnings, directions or notes of particular concern, that are not related to physical injury, as well as practices for which physical injury is not likely to occur.

2.6 - ADDRESSEES, SUPPLY AND STORAGE OF THE MANUAL

The instruction manual is intended for qualified technicians responsible for operating and managing the equipment throughout its service life.

It contains the necessary information to properly use the equipment and keep its functional and qualitative characteristics unchanged over time. All information and warnings for safe, correct use are also provided.

The instruction manual, as well as the declaration of conformity and/or test certificate, is an integral part of the equipment and must always accompany it whenever it is moved or resold. It is up to the user to keep this documentation intact for reference throughout the lifespan of the equipment.

WARNING!

Removing, rewriting or editing the pages of the manual and their contents is not allowed.

Keep the instruction manual near the equipment, in an accessible place known by all qualified technicians involved in using and running it.

PIETRO FIORENTINI S.p.A. shall not be held liable for any damage to people, animals and property caused by failure to adhere to the warnings and operating procedures described in this manual.

2.7 - LANGUAGE

The original instruction manual was drawn up in Italian.

Any translations into additional languages are to be made from the original instruction manual.

HAZARD!

The Manufacturer is not responsible for any incomplete translations. If any inconsistency is found, please refer to the text of the original manual.

If inconsistencies are found or the text does not make sense:

- stop any actions;
- immediately contact the relevant offices of PIETRO FIORENTINI S.p.A.

WARNING!

PIETRO FIORENTINI S.p.A. shall be held liable for the information provided in the original manual only.

2.8 - APPLIED RATING PLATES



WARNING!

**Removing nameplates and/or replacing them with other plates is strictly not allowed.
Should the plates be unintentionally damaged or removed, the customer must notify
PIETRO FIORENTINI S.p.A.**

The equipment and its accessories are provided with nameplates (from Id.1 to Id.2).

The rating plates specify identification details of the equipment and its accessories to be provided, if necessary, to PIETRO FIORENTINI S.p.A.

“Tab. 2.5” shows the nameplates applied:

| Id. | Type | Image |
|-----|---|--|
| 1 | NAMEPLATE REGULATOR (EC version) AND REGULATOR WITH IN LINE MONITOR FUNCTION |  |
| 2 | NAMEPLATE SLAM-SHUT VALVE |  |

Tab. 2.5

2.8.1 - GLOSSARY FOR RATING PLATES

The terms and abbreviations used on nameplates are described in "Tab. 2.6":

| Term | Description |
|-------------------------|---|
| AC | Accuracy class. |
| AG max | Slam-shut valve accuracy class due to pressure increase. "OPSO" (Over pressure shut off). |
| AG min | Slam-shut valve accuracy class due to pressure decrease. "UPSO"(Under pressure shut off). |
| bpu | Range of inlet pressure for which the regulator ensures a given accuracy class. |
| CE | Marking certifying compliance with applicable European directives. |
| Cg | Flow rate coefficient. |
| Class | Alphanumeric designation used for reference purposes related to a combination of mechanical and dimensional characteristics for flanges, in accordance with the relevant parts of EN 1759 series, which includes the word Class followed by a dimensionless whole number. |
| DN | Nominal size of connections. |
| Fail safe mode | Regulator reaction mode (Fail open or Fail close). |
| Flange | Type of flanged connections or type of connection thread. |
| Fluid | Type of fluid compatible with the equipment. |
| ID no. | Number of the Notified Body participating in the conformity assessment of the equipment. |
| Pilot | Pilot family. |
| PS | Maximum permissible pressure for which the equipment was designed. |
| Pumax | Maximum inlet pressure at which the regulator can operate continuously under specific conditions. |
| REGULATOR | Equipment family. |
| SG | Shut-off pressure class. |
| Slam-shut device | Slam-shut valve family. |
| S.n. | Equipment serial number. |
| Strength type | Strength class: Integral strength or differential strength (DS). |
| T | Permissible temperature range (min. and max.) for which the equipment was designed. |
| Tripping unit | Pressure switch family. |
| Type | Accessory type and family. |
| Wd | Full setpoint range that can be obtained from the regulator by adjusting and/or replacing certain components (e.g. replacement of valve seat or control element, e.g. spring). |
| Wdo | Full setpoint range with regard to tripping caused by increased pressure in the pressure switch incorporated in the slam-shut valve. This range can be obtained by adjusting and/or replacing the components (for example, spring or sensitive element). |
| Wds | Full setpoint range that can be obtained from the regulator by adjusting but not replacing the components. |
| Wdso | Full setpoint range with regard to tripping caused by increased pressure in the pressure switch incorporated in the slam-shut valve. This range can be obtained by adjusting but not replacing the components. |
| Wdu | Full setpoint range with regard to tripping caused by decreased pressure in the pressure switch incorporated in the slam-shut valve. This range can be obtained by adjusting and/or replacing the components (for example, spring or sensitive element). |

| Term | Description |
|-------------|---|
| Wdsu | Full setpoint range with regard to tripping caused by decreased pressure in the pressure switch incorporated in the slam-shut valve. This range can be obtained by adjusting but not replacing the components. |

Tab. 2.6

2.9 - GLOSSARY OF MEASUREMENT UNITS

| Type of measurement | Unit of measurement | Description |
|-----------------------------|---------------------|---------------------------------------|
| Volumetric flow rate | Sm ³ /h | Standard cubic metres per hour |
| | Scfh | Standard cubic feet per hour |
| Pressure | bar | Unit of measurement in the CGS system |
| | psi | Pounds per square inch |
| | "wc | Water column inch |
| | Pa | Pascal |
| Temperature | °C | Degree centigrade |
| | °F | Fahrenheit degree |
| | K | Kelvin |
| Tightening torque | Nm | Newton metre |
| | ft-lbs | Foot per pound |
| Sound pressure | dB | Decibel |
| Other measures | V | Volt |
| | W | Watt |
| | Ω | Ohm |

Tab. 2.7

2.10 - QUALIFIED PROFESSIONAL FIGURES

Qualified operators in charge of using and managing the equipment throughout its technical service life:

| Professional figure | Definition |
|---|--|
| Mechanical maintenance technician | <p>Qualified technician able to:</p> <ul style="list-style-type: none"> perform preventive/corrective maintenance operations on all mechanical parts of the equipment subject to maintenance or repair; access all device parts for visual inspection, equipment checks, adjustments and calibrations. <p>The maintenance mechanical technician is not authorised to operate on live electrical systems (if any).</p> |
| Electrical maintenance technician | <p>Qualified technician able to:</p> <ul style="list-style-type: none"> perform preventive/corrective maintenance operations on all electrical parts of the device subject to maintenance or repair; read wiring diagrams and check the correct functional cycle; perform adjustments and operate on electrical systems for maintenance, repair and replacement of worn parts. <p>The electrical maintenance technician can operate in the presence of voltage inside electrical panels, junction boxes, control equipment etc. only if he/she is deemed to be suitable (S.P.).</p> <p>For general requirements, refer to the IEC EN 50110-1:2014 standard.</p> |
| Worker in charge of transport, handling, unloading and placement on site | <p>Operator qualified to:</p> <ul style="list-style-type: none"> use lifting equipment; handle materials and equipment. <p>The equipment must be lifted and handled strictly in accordance with the instructions provided by the manufacturer as well as the regulations in force at the place where the equipment is installed.</p> |
| Installer | <p>Qualified operator able to:</p> <ul style="list-style-type: none"> carry out all the operations necessary to properly install the equipment; perform all the operations necessary for the proper functioning of the equipment and the system in safety. |
| User's technician | <p>Technician trained and authorized to use and manage the equipment for the activities for which it was supplied. They must:</p> <ul style="list-style-type: none"> be able to perform all operations required to properly run the equipment and the system, ensuring their own safety and that of any personnel on site; have proven experience in properly using the equipment similar to that described in this manual, and be trained, informed and instructed in this regard. <p>The technician may carry out maintenance only if authorised/qualified to do so.</p> |

Tab. 2.8

3 - SAFETY

3.1 - GENERAL SAFETY WARNINGS

WARNING!

The equipment described in this instruction manual is:

- a device subjected to pressure in pressurised systems;
- normally installed in systems carrying flammable gases (for example: natural gas).

WARNING!

If the gas used is a combustible gas, the installation area of the equipment is defined as a “danger zone” as there are residual risks that potentially explosive atmospheres may be generated.

In “danger zones” and in close proximity thereto:

- there must not be any effective sources of ignition;
- no smoking.

ATTENTION!

Authorised operators must not carry out operations or services on their own initiative that do not fall within their competence.

Never operate the equipment:

- while under the influence of intoxicating substances such as alcohol;
- if you are using drugs that may lengthen reaction times.

NOTICE!

The employer must train and inform operators on how to behave during operations and on the equipment to be used.

Before installation, commissioning or maintenance, operators must:









- take note of the safety regulations applicable to the place of installation they are working in;
- obtain the necessary permits to operate when required;
- wear the personal protective equipment required by the procedures described in this instruction manual;
- ensure that the required collective protective equipment and safety information are available in the area they are operating in.

3.2 - PERSONAL PROTECTIVE EQUIPMENT

"Tab. 3.9" shows the personal protective equipment (PPE) and its description. An obligation is associated with each symbol.

Personal protective equipment means any equipment intended to be worn by the worker in order to protect them against one or several risks that are likely to threaten their safety or health during work.

For the operators in charge, depending on the type of work requested, the most appropriate PPE of the following will be reported and must be used:

| Symbol | Meaning |
|---|---|
|  | Obligation to use safety or insulated gloves. Indicates a requirement for the personnel to use safety or insulated gloves. |
|  | Obligation to use safety goggles. Indicates a requirement for personnel to use protective goggles for eye protection. |
|  | Obligation to use safety shoes. Indicates a requirement for the personnel to use accident-prevention safety shoes. |
|  | Obligation to use noise protection equipment. Indicates a requirement for the personnel to use ear muffs or ear plugs to protect their hearing. |
|  | Obligation to wear protective clothing. Indicates a requirement for the personnel to wear specific protective clothing. |
|  | Obligation to use a protective mask. Indicates a requirement for the personnel to use respiratory masks in the event of a chemical risk. |
|  | Obligation to use a protective helmet. Indicates a requirement for the personnel to use protective helmets. |
|  | Obligation to wear high visibility vests. Indicates a requirement for the personnel to use high visibility vests. |

Tab. 3.9

WARNING!

Each licensed operator is obliged to:

- **take care of his/her own health and safety and that of other people in the workplace who are affected by his/her actions or omissions, in accordance with the training, instructions and equipment provided by the employer;**
- **appropriately use the PPE made available;**
- **immediately report to the employer, the manager or the person in charge any deficiencies in the equipment and devices, as well as any dangerous conditions they may become aware of.**

3.3 - RESIDUAL RISKS

In accordance with the requirements of PED 2014/68/EU, point 1.2 of Annex I, below is an assessment of the risks associated with the equipment and an indication of the principles adopted for their prevention, according to the following classification:

- a) Elimination and/or reduction of the risk.
- b) Application of appropriate protective measures.
- c) Information to users about residual risks.

3.3.1 - TABLE SHOWING RESIDUAL RISKS DUE TO PRESSURE

| Risk and hazard | Event and Cause | Effect and consequence | Solution and prevention |
|---|---|--|--|
| Pressurised gas leak. Projection of metallic and non-pressurised parts. | <ul style="list-style-type: none"> Violent impact; Impact (also due to falling, improper handling, etc.). | <ul style="list-style-type: none"> Deformation; Broken connections and, if pressurised, even burst. | <p>a. Handling and installation with appropriate devices to avoid localised stress.</p> <p>b. Installation in suitable places and spaces with appropriate guards and packaging.</p> <p>c. Information in the instructions for use and warning.</p> |
| Pressurised gas leak. Projection of metallic and non-pressurised parts. | <ul style="list-style-type: none"> Use of inappropriate fluids. | <ul style="list-style-type: none"> Corrosion; Embrittlement; Explosion. | <p>a. The user must check compliance of the used fluid with the specifications on the data plate.</p> |
| Pressurised gas leak. Projection of metallic and non-pressurised parts. | <ul style="list-style-type: none"> Operation at temperatures below the minimum permissible temperature. | <ul style="list-style-type: none"> Embrittlement; Breakage; Explosion. | <p>a. Install in places where the temperature is not below the minimum permissible temperature and/or insulate the equipment adequately.</p> <p>b. The minimum temperature allowed is indicated on the data plate.</p> |
| Pressurised gas leak. Projection of metallic and non-pressurised parts. Explosion. | <ul style="list-style-type: none"> Overpressure or exceedance of the rated limit values (maximum pressure allowed) | <ul style="list-style-type: none"> Explosion; Breaks; Cracks; Permanent deformations. | <p>a. The device has appropriate design safety margins.</p> <p>b. The user must check the maximum pressure applicable to the equipment.</p> <p>c. The maximum allowable pressure is highlighted on the appropriate plate on the equipment.</p> |
| Falling of the equipment. | <ul style="list-style-type: none"> Dangerous handling. | <ul style="list-style-type: none"> Deformation; Cracking; Breakage. | <p>b. The user must have suitably sized lifting equipment.</p> <p>c. The above requirements are referred to in the equipment use and warning manual.</p> |
| Pressurised fluid leakage. Projection of metallic and non-pressurised parts. | <ul style="list-style-type: none"> Incorrect fixing of the equipment. | <ul style="list-style-type: none"> Deformation; Breakage. | <p>a. The device is equipped with unified type process connections and compression fittings.</p> <p>b. The user must ensure correct fixing to the line.</p> <p>c. Directions in the instructions for use and warning.</p> |
| Explosion of the device. Pressurised fluid leakage. Projection of metallic parts. | <ul style="list-style-type: none"> Operation at temperatures above the maximum permissible temperature. | <ul style="list-style-type: none"> Reduction of mechanical resistance and breakage of the device; Explosion. | <p>a. The user must equip the system with suitable safety and control devices.</p> <p>b. The maximum temperature allowed is indicated on the data plate.</p> |
| Pressurised gas leak. | <ul style="list-style-type: none"> Device maintenance with the system running. | <ul style="list-style-type: none"> Inappropriate opening of pressurised chambers. | <p>a. The user must perform any maintenance with the equipment not in operation.</p> <p>b. The above requirements are referred to in the use and warning manual.</p> |

| Risk and hazard | Event and Cause | Effect and consequence | Solution and prevention |
|--|---|--|---|
| Pressurised gas leak. Projection of metallic and non-pressurised parts. | <ul style="list-style-type: none"> External loads bearing on the device. | <ul style="list-style-type: none"> Deformation; Cracking and slot formation; If under pressure, burst also. | a. With the exclusion of what is set out in the project, the user must verify that no additional concentrated load bears on the device. |
| Pressurised gas leak. Projection of metallic and non-pressurised parts. | <ul style="list-style-type: none"> Electrostatic potential, differential stray currents. | <ul style="list-style-type: none"> Corrosion localised in the device. | b. The user must equip the device with the necessary protection and earthing devices. c. The above requirements are referred to in the use and warning manual. |
| Pressurised gas leak. Projection of metallic and non-pressurised parts. | <ul style="list-style-type: none"> Humidity; Environments with aggressive atmosphere. | <ul style="list-style-type: none"> Deterioration of external surfaces; Corrosion. | a. The user must periodically check the state of conservation of the external surfaces. b. The above requirements are referred to in the use and warning manual. |

Tab. 3.10

3.3.2 - TABLE OF RESIDUAL RISKS FOR POTENTIALLY EXPLOSIVE ATMOSPHERES

“Tab. 3.11” shows the conditions that can lead to the generation of a potentially explosive atmosphere respectively for:

- DIVAL 700 pressure regulator;
- the LA slam-shut valve.

Considering that the silencer does not have active functional parts, in this analysis it is considered an integral part of the DIVAL 700 regulator.

The table is valid for use with natural gas with a density of no more than 0.8; for different densities, the installation and environmental conditions must also be evaluated.

WARNING!

If the gas used is a combustible gas, the installation area of the equipment is defined as a “danger zone” as there are residual risks that potentially explosive atmospheres may be generated.

There must be no effective sources of ignition in “danger zones” and in close proximity thereto.

| Operating conditions | Potentially explosive atmosphere | Normative references | Management measures included in the instructions for use and warning |
|---|----------------------------------|---|--|
| First start-up | No | <ul style="list-style-type: none"> • During the production cycle and before the CE marking according to Directive 2014/68/EU, the external tightness of the equipment is checked at a value of 1.1 PS (in accordance with Standard EN 334). • Before commissioning, the external sealing of the system portion on which the equipment is installed is checked at a suitable pressure (in accordance with the provisions of standards EN 12186 and EN 12279). | The instructions for use indicate the need to meet the requirements in Standards EN 12186 and EN 12279. |
| Operation in normal conditions | No | <p>The indications in the previous point apply, in addition:</p> <ul style="list-style-type: none"> • the equipment is installed outdoors or in an environment with natural ventilation (in accordance with Standards EN 12186 and EN 12279); • the installation is subject to surveillance according to current national rules/good practice/the equipment manufacturer's instructions (in accordance with the provisions of Standard EN 12186 and Standard EN 12279). | <p>The instructions for use indicate that:</p> <ul style="list-style-type: none"> • any environment in which the equipment is installed must meet the requirement of Standards EN 12186 and EN 12279; • periodic checks and maintenance must be carried out during surveillance in accordance with the national rules in force (if any), and with the specific manufacturer's recommendations. |
| Breakage of the control head diaphragm (malfunction) | No | <p>This event must be considered a rare malfunction.</p> <p>All atmospheric pressure chambers delimited on at least one side by a diaphragm must be channelled to a safe area (in accordance with the provisions of Standard EN 12186 and Standard EN 12279).</p> | The instructions for use indicate the need to meet the requirements of Standards EN 12186 and EN 12279. |

| Operating conditions | Potentially explosive atmosphere | Normative references | Management measures included in the instructions for use and warning |
|---|----------------------------------|---|--|
| Breakage of other non-metallic parts (malfunction) | No | This type of malfunction is not reasonably expected as it involves static sealing (to the outside). | - |
| Decommissioning | No | <ul style="list-style-type: none"> The pressure of the system section in which the equipment is installed must be reduced with appropriate vent lines channelled to a safe area (in accordance with the provisions of Standard EN 12186 and Standard EN 12279). The residual gas must be discharged as indicated above. | The instructions for use indicate the need to meet the requirements of Standards EN 12186 and EN 12279 |
| Reboot | No | <ul style="list-style-type: none"> After reassembling the regulator, carry out an external leakage test at a convenient pressure value as specified by the manufacturer. Before commissioning, the external sealing of the system portion on which the equipment is installed is checked at a suitable pressure (in accordance with the provisions of standards EN 12186 and EN 12279). | The instructions for use indicate: <ul style="list-style-type: none"> the minimum conditions for testing internal leakage; the need to meet the requirements of Standards EN 12186 and EN 12279. |

Tab. 3.11

3.4 - OBLIGATIONS AND PROHIBITIONS

The following is a list of obligations and prohibitions to be observed for the safety of the operator.

It is mandatory to:



- carefully read and understand the instructions for use and warning;
- check whether the downstream equipment is suitably sized according to the performance required of the regulator in the actual operating condition;
- before installing the equipment, the data on the nameplates must be checked;
- Avoid violent shocks and impacts that could damage the equipment and, as a result, cause the pressure fluid to escape.

It is forbidden to:

- operate in various capacities on the equipment without the PPE indicated in the work procedures described in these use and warning instructions;
- operate in the presence of open flames or bring open flames close to the work area;
- smoke near the equipment or while working on it;
- use the equipment with parameters other than those indicated on the nameplate;
- use the equipment with fluids other than those indicated on the nameplate and in these use and warning instructions;
- use the equipment outside the operating temperature range specified on the nameplate and in these use and warning instructions;
- service the equipment with the system portion, on which it is installed, running;
- install or use the equipment in environments other than those specified in these instructions for use and warning.

3.5 - SAFETY PICTOGRAMS

The following safety pictograms may be shown on the equipment and/or packaging PIETRO FIORENTINI S.p.A.:

| Symbol | Meaning |
|---|---|
|  | Symbol used to identify an ELECTRICAL HAZARD. |
|  | Symbol used to identify a GENERIC HAZARD. |

Tab. 3.12

HAZARD!

It is absolutely forbidden to remove the safety pictograms on the equipment.

The user is required to replace the safety pictograms which, following wear, removal or tampering, are illegible.

3.6 - NOISE LEVEL

Depending on the operating conditions, use and configuration required, the equipment may generate noise beyond the limits allowed by current legislation in the country of installation.

For the value of the noise generated by the equipment and further information, contact PIETRO FIORENTINI S.p.A.

ATTENTION!

The obligation to use earmuffs or ear plugs to protect the operator's hearing remains in the event that the noise in the installation environment of the equipment (depending on specific operating conditions) exceeds the value of 85 dBA.

4 - DESCRIPTION AND OPERATION

4.1 - GENERAL DESCRIPTION

DIVAL 700 is a direct acting pressure regulator for medium and low pressure that reduces the inlet gas pressure while maintaining a stable downstream value even when the required flow rate varies within the operating conditions of the equipment.

The main elements of the equipment are (see Fig. 4.1):

| Pos. | Description | Pos. | Description |
|------|----------------|------|-----------------|
| 1 | Regulator body | 6 | Lever mechanism |
| 2 | Valve seat | 7 | Setting spring |
| 3 | Plug | 8 | Relief spring |
| 4 | Rod | 9 | Limit switches |
| 5 | Main diaphragm | | |

Tab. 4.13




Fig. 4.1. General description DIVAL 700

4.1.1 - REGULATOR REACTION MODES

The DIVAL 700 equipment is a direct acting regulator with a “fail open” reaction (on-opening reaction), that is, it opens in the event of:

- breakage of main diaphragm
- downstream pressure signal missing.

4.2 - OPERATION




Fig. 4.2. Operation DIVAL 700

In the absence of pressure, the plug (3) is held in the open position by the spring thrust acting on the plug (3) through the engagement of the rod (4) by the lever mechanism (6).

The downstream pressure value (Pd) is regulated by comparing:

- the load of the setting spring (7)
- the thrust that the downstream pressure (Pd) itself exerts on the main diaphragm (5)
- the thrust resulting from the upstream pressure (Pu) on the plug (3).

The main diaphragm (5) moves the rod (4) and the plug (3). The rod (4) moves perpendicularly with respect to the gas flow. In the case of zero flow, the plug (3) closes on the seat and allows the downstream pressure not to rise above the closing pressure value.

Under normal work conditions, the plug (3) positions itself so as to keep the pressure downstream (Pd) around the pre-established calibration value.

The position of the plug (3) is controlled by the movements of the main diaphragm (5). The forces which affect the position of the plug (3) are:

- towards the closed position: the thrust resulting from the downstream pressure (Pd) in the chamber (C)
- towards the open position: the load of the setting spring (7).

Variations in the upstream pressure (Pu) change the value of the downstream pressure (Pd) in relation to the cross-section of the mounted valve seat and the setting spring.

The limit switch (9) positioned in the regulator head eliminates the effects of possible overpressure below the main diaphragm (5) or overloading of the setting spring (7), such as damage to the main diaphragm (5) or excessive load on the plug.

If, during operation, the following should occur:

| Operating conditions | Operating consequences | Concluding outcome |
|--|--|--|
| <p>Decrease in downstream pressure (Pd) for:</p> <ul style="list-style-type: none"> • increase in the requested flow rate; • drop in pressure upstream (Pu). | <p>The thrust on the main diaphragm (5) is less than the load on the setting spring (7) and moves the plug (3) towards the open position.</p> | <p>Increase in flow until the preset value of the downstream pressure (Pd) is restored.</p> |
| <p>Increased downstream pressure (Pd) due to:</p> <ul style="list-style-type: none"> • drop in the requested flow rate; • increase in pressure upstream (Pu). | <p>The thrust on the main diaphragm (5) is greater than the load on the setting spring (7) and moves the plug (3) towards the closed position.</p> | <p>Decrease in flow rate until the preset value of downstream pressure (Pd) is restored.</p> |

Tab. 4.14

4.3 - INTENDED USE

4.3.1 - ENVISAGED USE

The equipment in question is intended for:

| Operation | Permitted | Not permitted | Work environment |
|---|--|---|--|
| Adjustment of the downstream pressure for: | Gaseous, and non-corrosive, fluids that have been filtered beforehand. | <ul style="list-style-type: none"> Liquids. Any product other than those permitted. | Installations for the transport and distribution of gas fuel to supply networks for: <ul style="list-style-type: none"> civil use; industrial use. |

Tab. 4.15

The equipment in question is used as a main regulator and in-line monitor regulator.

It was designed to be used exclusively within the limits specified on the nameplate and according to the instructions and limits of use referred to in this manual.

Safe work conditions are as follows:

- use within the limits stated on the nameplate and in this manual;
- compliance with the user manual procedures;
- routine maintenance to be carried out when and how recommended;
- special maintenance to be carried out if required;
- do not tamper with and/or bypass the safety devices.

4.3.2 - REASONABLY FORESEEABLE MISUSE

Reasonably foreseeable misuse means the use of the equipment in a way not foreseen in the phase but which can result from readily foreseeable human behaviour:

- corrosive fluids;
- fluids not properly treated upstream;
- liquids;
- instinctive reaction of an operator in the event of a malfunction, accident or breakdown while using the equipment;
- behaviour resulting from pressure to keep the equipment running under all circumstances;
- behaviour resulting from carelessness;
- behaviour resulting from the use of the equipment by unauthorised and unsuitable people;
- using the equipment in a manner other than that referred to under "4.3.1 - Envisaged use".

Any use of the equipment other than the intended use must be previously approved in writing by PIETRO FIORENTINI S.p.A. If no written approval is provided, use shall be considered improper.

In the event of "improper use", PIETRO FIORENTINI S.p.A. shall not be held liable for any damage caused to people or property, and any type of warranty on the equipment shall be deemed void.

4.3.3 - TYPES OF FLUIDS

The equipment works with combustible gases used:

- in pressure control stations according to EN 12186 or EN 12279;
- in transmission and distribution networks.
- in commercial and industrial plants (after checking by contacting the Manufacturer).

NOTICE!

The equipment may be also used with inert gases, subject to verification by contacting the manufacturer.

4.4 - TECHNICAL FEATURES/PERFORMANCE

The DIVAL 700 equipment is a regulator for medium and low pressure. The regulation system is unbalanced with an outlet pressure that varies with the inlet pressure.

The main specifications for this regulator are:

| Technical features | |
|--------------------------------|---|
| Maximum allowable pressure | Up to 20 bar |
| Ambient temperature range | -20 °C - +60 °C |
| Inlet gas temperature range | -20 °C - +60 °C |
| Inlet pressure range (bpu) | Depending on the valve seat installed: <ul style="list-style-type: none"> • 1/4": 8,63 bar • 3/8": 8,63 bar • 1/2": 8,63 bar • 3/4": 5 bar • 1": 3,45 bar • 1" 1/2: 2,07 bar |
| Possible regulation range (Wd) | 0,005 - 1,45 bar |
| Minimum differential pressure | 0.1 bar |
| Accuracy class (AC) | up to 5 (depending on operating conditions) |
| Lock up pressure class (SG) | up to 5 (depending on operating conditions) |
| Connections | <ul style="list-style-type: none"> • Flanged: class 150 RF according to ASME B16.5 and ASME B16.42 • ANSI Class 125 FF according to ASME B16.1, PN16/25 according to ISO 7005-1 and ISO 7005-2 • Threaded: Rp EN 10226-1, NPT ASME B1.20.1 (2" only) |

Tab. 4.16

| Coefficients Cg and K1 1" DN 25 | | | | | | | |
|-----------------------------------|-------------|-----|-----|------|-----|----|----|
| Seat | | 6.5 | 9.5 | 12.7 | 19 | 25 | 32 |
| Head | Coefficient | | | | | | |
| BP/MP | Cg | 50 | 92 | 161 | 253 | - | - |
| | K1 | 98 | 91 | 97 | 93 | - | - |
| TR | Cg | 50 | 93 | 180 | 317 | - | - |
| | K1 | 98 | 91 | 97 | 93 | - | - |

Tab. 4.17

| Coefficients Cg and K1 1" 1/2 DN 40 | | | | | | | |
|---------------------------------------|-------------|-----|-----|------|-----|-----|-----|
| Seat | | 6.5 | 9.5 | 12.7 | 19 | 25 | 32 |
| Head | Coefficient | | | | | | |
| BP/MP | Cg | 50 | 107 | 141 | 158 | 332 | 393 |
| | K1 | 119 | 101 | 94 | 96 | 102 | 91 |
| TR | Cg | 50 | 107 | 170 | 307 | 429 | 530 |
| | K1 | 119 | 101 | 94 | 91 | 85 | 85 |

Tab. 4.18

| Coefficients Cg and K1 2" DN 50 | | | | | | | |
|-----------------------------------|-------------|-----|-----|------|-----|-----|-----|
| Seat | | 6.5 | 9.5 | 12.7 | 19 | 25 | 32 |
| Head | Coefficient | | | | | | |
| BP/MP | Cg | 50 | 107 | 151 | 171 | 346 | 440 |
| | K1 | 115 | 101 | 93 | 89 | 86 | 86 |
| TR | Cg | 50 | 109 | 179 | 320 | 447 | 570 |
| | K1 | 115 | 104 | 93 | 89 | 86 | 86 |

Tab. 4.19

4.4.1 - VARIATION OF OUTLET PRESSURE AS INLET PRESSURE CHANGES BY 0.5 BAR

| Springs (dimensions and colours) | HEADER Ø 280 BP/MP | | | | | |
|---|--------------------|------|------|------|-----|--------|
| | Size [inches] | | | | | |
| | 1/4" | 3/8" | 1/2" | 3/4" | 1" | 1" 1/4 |
| d= 3,2 De= 65 Lo= 180 2701175 White | 0.2 | 0.4 | 0.5 | 1.3 | 2.4 | 3.4 |
| d= 3,5 De= 65 Lo= 180 2701345 Yellow | 0.2 | 0.4 | 0.5 | 1.3 | 2.4 | 3.4 |
| d= 4 De= 65 Lo= 180 2701620 Orange | 0.2 | 0.4 | 0.6 | 1.3 | 2.4 | 3.4 |
| d= 4,5 De= 65 Lo= 180 2701860 Red | 0.3 | 0.5 | 0.7 | 1.4 | 2.6 | 3.5 |
| d= 5 De= 65 Lo= 180 2702190 Green | 0.3 | 0.5 | 0.9 | 1.5 | 2.3 | 3.6 |
| d= 5,5 De= 65 Lo= 180 2702370 Black | 0.4 | 0.6 | 0.9 | 1.6 | 2.4 | 3.7 |
| d= 6 De= 65 Lo= 180 2702540 Blue | 0.4 | 0.7 | 1.1 | 1.9 | 2.6 | 3.8 |
| d= 6,5 De= 65 Lo= 180 2702730 Light Blue | 0.9 | 1 | 1.3 | 2.8 | 3.1 | 3.9 |
| d= 7 De= 65 Lo= 180 2702950 Brown | 1 | 1.1 | 1.5 | 3.5 | 3.7 | 4,6 |

d = Wire Diameter (mm) **Lo** = Spring Length (mm) **De** = External Diameter (mm)

Tab. 4.20

| Springs (dimensions and colours) | HEADER Ø 280 TR | | | | | |
|---|-----------------|------|------|------|----|--------|
| | Size [inches] | | | | | |
| | 1/4" | 3/8" | 1/2" | 3/4" | 1" | 1" 1/4 |
| d= 7 De= 65 Lo= 180 2702940 Light Blue | 2 | 3 | 5 | 11 | 18 | 28 |
| d= 7,5 De= 65 Lo= 180 2702125 White/Yellow | 2 | 3 | 5 | 11 | 18 | 29 |
| d= 8 De= 65 Lo= 180 2703325 White/Orange | 2 | 3 | 6 | 11 | 18 | 29 |

d = Wire Diameter (mm) **Lo** = Spring Length (mm) **De** = External Diameter (mm)

Tab. 4.21

4.4.2 - SPRING SETTING RANGE

4.4.2.1 - INLET PRESSURE 1.7 BAR

| Springs (dimensions and colours) | HEADER Ø 280 BP/MP | | | | | | | | | | | |
|---|--------------------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| | Size [inches] | | | | | | | | | | | |
| | 1/4" | | 3/8" | | 1/2" | | 3/4" | | 1" | | 1" 1/4 | |
| | Pd min | Pd max | Pd min | Pd max | Pd min | Pd max | Pd min | Pd max | Pd min | Pd max | Pd min | Pd max |
| d= 3,2 De= 65 Lo= 180 2701175 White | 5 | 13 | 6 | 16 | 7 | 17 | 10 | 20 | 13 | 22 | 16 | 26 |
| d= 3,5 De= 65 Lo= 180 2701345 Yellow | 7 | 19 | 8 | 21 | 8 | 22 | 11 | 25 | 14 | 27 | 18 | 32 |
| d= 4 De= 65 Lo= 180 2701620 Orange | 10 | 32 | 12 | 34 | 12 | 34 | 15 | 38 | 19 | 40 | 22 | 45 |
| d= 4,5 De= 65 Lo= 180 2701860 Red | 15 | 53 | 17 | 55 | 18 | 56 | 21 | 60 | 25 | 62 | 25 | 67 |
| d= 5 De= 65 Lo= 180 2702190 Green | 23 | 80 | 24 | 83 | 24 | 84 | 29 | 89 | 32 | 90 | 36 | 97 |
| d= 5,5 De= 65 Lo= 180 2702370 Black | 38 | 127 | 41 | 129 | 43 | 131 | 48 | 143 | 48 | 142 | 52 | 147 |
| d= 6 De= 65 Lo= 180 2702540 Blue | 50 | 173 | 53 | 178 | 55 | 179 | 56 | 188 | 61 | 191 | 65 | 197 |
| d= 6,5 De= 65 Lo= 180 2702730 Light Blue | 81 | 280 | 82 | 280 | 82 | 287 | 88 | 299 | 94 | 303 | 98 | 306 |
| d= 7 De= 65 Lo= 180 2702950 Brown | 95 | 372 | 100 | 380 | 105 | 386 | 110 | 395 | 113 | 401 | 120 | 404 |

d = Wire Diameter (mm) **Lo** = Spring Length (mm) **De** = External Diameter (mm)

Tab. 4.22

4.4.2.2 - INLET PRESSURE 3.4 BAR

| Springs (dimensions and colours) | HEADER Ø 280 TR | | | | | | | | | | | |
|---|-----------------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| | Size [inches] | | | | | | | | | | | |
| | 1/4" | | 3/8" | | 1/2" | | 3/4" | | 1" | | 1" 1/4 | |
| | Pd min | Pd max | Pd min | Pd max | Pd min | Pd max | Pd min | Pd max | Pd min | Pd max | Pd min | Pd max |
| d= 7 De= 65 Lo= 180 2702940 Light Blue | 164 | 753 | 170 | 778 | 188 | 779 | 207 | 807 | 259 | 844 | 261 | 863 |
| d= 7,5 De= 65 Lo= 180 2702125 White/Yellow | 292 | 1150 | 317 | 1160 | 324 | 1156 | 351 | 1170 | 365 | 1194 | 380 | 1216 |
| d= 8 De= 65 Lo= 180 2703325 White/Orange | 357 | 1391 | 369 | 1402 | 347 | 1403 | 385 | 1412 | 400 | 1430 | 458 | 1454 |

d = Wire Diameter (mm) **Lo** = Spring Length (mm) **De** = External Diameter (mm)

Tab. 4.23

4.5 - POSSIBLE CONFIGURATIONS

4.5.1 - CONTROL HEADS

“Tab. 4.24” lists the possible combinations of sizes and control heads for the equipment DIVAL 700.

| | | Size [inches] DN [mm] | | |
|---------------------------------|---------|-------------------------|-----------|---------|
| | | 1" 25 | 1" ½ 40 | 2" 50 |
| T E S T A T E | BP / MP | Yes | Yes | Yes |
| | TR | Yes | Yes | Yes |

Tab. 4.24

4.5.2 - ACCESSORIES

The DIVAL 700 equipment can have different configurations through the installation of the following accessories:

- Regulator with monitor function
- LA incorporated slam-shut valve.

The possible configurations are listed in “Tab. 4.25”:

| DIVAL 700 | Regulator-monitor | LA |
|---------------------------------|-------------------|-----|
| Regulator-monitor | - | Yes |
| LA incorporated slam-shut valve | Yes | - |

Tab. 4.25

The accessories can be installed directly at the factory or, at a later time, directly on site.

NOTICE!

The installation of accessories is described in the relevant chapter of this manual.

4.5.3 - REGULATOR WITH MONITOR FUNCTION

The regulator with monitor function (1) is used to keep the downstream pressure value (P_d) within the preset limits in case of failure of the main regulator.

The regulator with monitor function is installed upstream of the main pressure regulator.




Fig. 4.3. Regulator with monitor function

OPERATION IN STAND-BY CONDITIONS

The regulator with monitor function is open during normal operation since it is calibrated higher than the calibration of the main regulator (2).





Fig. 4.4. In-line operation of regulator-monitor in stand-by conditions

OPERATION IN THE EVENT OF FAILURE OF THE MAIN REGULATOR



UPSTREAM PRESSURE

DOWNSTREAM PRESSURE

Fig. 4.5. Operation of regulator-monitor with main regulator in faulty conditions

In the event of failure of the main regulator (2), the regulator with monitor function (1) will intervene maintaining the downstream pressure value (P_d) within the established limit for its calibration.

If, during operation, the following should occur:

| Operating conditions | Operating consequences | Concluding outcome |
|---|--|--|
| Decrease in downstream pressure (P_d) for: <ul style="list-style-type: none"> increase in the requested flow rate; drop in pressure upstream (P_u). | Unbalance that causes the plug (3) to open. | Increase in flow until the preset value of the downstream pressure (P_d) is restored. |
| Increased downstream pressure (P_d) due to: <ul style="list-style-type: none"> drop in the requested flow rate; increase in pressure upstream (P_u). | Unbalance that causes the plug (3) to close. | Decrease in flow rate until the preset value of downstream pressure (P_d) is restored. |

Tab. 4.26

4.5.4 - SLAM-SHUT VALVE

The slam-shut valve is a safety device is used to shut off the gas flow if the pressure value at the control point exceeds the calibration value of the valve itself.

The slam-shut valve incorporated in the regulator consists of:

- a control system;
- the slam-shut device mechanism.

In the event of tripping, the slam-shut valve shuts off the supply to the regulator.

4.5.4.1 - LA INCORPORATED SLAM-SHUT VALVE

The LA incorporated slam-shut valve can be operated:

- by the intervention spring
- manually.

The main features of the LA incorporated slam-shut valve are:

- tripping due to downstream pressure increase and/or decrease;
- design pressure: 20 bar for all accessory components;
- local close button (can be omitted on request).

| Slam-shut valve type | | Set | Operating range (bar) | AG |
|----------------------|----|-----|-----------------------|----|
| LA | BP | max | 0.03 - 0.18 | 10 |
| | | min | 0.006 - 0.06 | 30 |
| LA | MP | max | 0.14 - 0.179 | 10 |
| | | | 0.18 - 0.45 | 5 |
| | | min | 0.01 - 0.059 | 30 |
| | | | 0.06 - 0.24 | 10 |
| LA | TR | max | 0.25 - 1.29 | 10 |
| | | | 1.3 - 5.5 | 5 |
| | | min | 0.1 - 3.5 | 10 |

Tab. 4.27

The incorporated LA slam-shut valve consists of (see Fig. 4.6):

| Pos. | Description | | |
|------|-----------------|----|--|
| 1 | Plug pad | 6 | Tripping spring due to pressure increase |
| 2 | Reset knob | 7 | Tripping spring due to pressure decrease |
| 3 | Coupling device | 8 | Spring support |
| 4 | Rod | 9 | Control shaft |
| 5 | Diaphragm | 10 | Sensor |

Tab. 4.28

OPERATION

In the control head (C), the downstream pressure (Pd) acts on the diaphragm (5), which, integral with the control shaft (9), receives an antagonistic force via the springs (6, 7), which causes the pressure to rise or fall.

In the event of tripping due to a pressure surge:


- the downstream pressure (Pd) exceeds the calibration value
- the load on the diaphragm (6) increases until the resistance of the spring (6) is overcome
- movement to the open position of the drive shaft (9) moves the touch probe (10) via the cam, disengaging the lever mechanism.

In the event of a tripping due to pressure drop:

- the downstream pressure (Pd) drops below the calibration value
- the spring holder (7) stops the stroke
- movement to the closed position of the drive shaft (9) moves the touch probe (10) via the cam, disengaging the lever mechanism.

To reset the LA slam-shut valve:

- pull the reset knob (2) downwards until the lever mechanism is reengaged
- wait for the upstream pressure (Pu) to pass downstream of the plug (1), balancing it
- press the reset knob (2) into its seat.



UPSTREAM PRESSURE **DOWNSTREAM PRESSURE**

Fig. 4.6. DIVAL 700 with incorporated LA slam-shut valve

5 - TRANSPORT AND HANDLING


5.1 - SPECIFIC WARNINGS FOR TRANSPORT AND HANDLING

NOTICE!

Transport and handling must be carried out by personnel:

- qualified (specially trained);
- who are familiar with accident prevention and workplace safety regulations;
- authorised to use lifting equipment;
- in compliance with the regulations in force in the country of destination of the equipment.

Transport with forklift or crane

| | |
|--|--|
| Operator qualification | Person in charge of transport, handling, unloading and placing on site |
| PPE required |  <p>WARNING!</p> <p>The PPE listed in this table is related to the risk associated with the equipment. For the PPE required to protect against risks associated with the workplace, installation or operating conditions, please refer to:</p> <ul style="list-style-type: none"> • the regulations in force in the country of installation; • <u>any information provided by the Safety Manager at the installation facility.</u> |
| Lifting equipment | Hoist crane, forklift truck or other suitable equipment. |
| Weights and dimensions of the equipment | For dimensions and weights please refer to “5.2 - Physical characteristics of the equipment”. |

Tab. 5.29

5.1.1 - PACKAGING AND FASTENERS USED FOR TRANSPORT

The transport packaging is designed and manufactured to avoid damage during normal transport, storage and handling. The equipment and spare parts must be kept in their packaging until they are installed.




Upon receiving the equipment:

- make sure that no part has been damaged during transport and/or handling;
- immediately report any damage found to PIETRO FIORENTINI S.p.A..

! NOTICE!

PIETRO FIORENTINI S.p.A. shall not be liable for any damage to people or property caused by accidents due to failure to comply with the instructions provided in this manual.

“Tab. 5.30” shows the types of packaging used:

| Ref. | Type of packaging | Image |
|------|-------------------|---|
| A | Cardboard box |  |
| B | Wooden box |  |
| C | Pallet |  |

Tab. 5.30

5.2 - PHYSICAL CHARACTERISTICS OF THE EQUIPMENT

5.2.1 - DIVAL 700




Fig. 5.7. DIVAL 700 physical characteristics

| DIVAL 700 overall dimensions | | | | |
|----------------------------------|------------------|---------|---------|-----------|
| Size [inches] | 1" | 1" ½ | 2" | Rp 2"x 2" |
| Nominal diameter [mm] | 25 | 40 | 50 | 50 |
| S | 183 | 223 | 254 | 152.4 |
| A | 145 | 145 | 145 | 145 |
| B | 343 | 343 | 343 | 343 |
| B1 | 433 | 433 | 433 | 433 |
| D | 280 | 280 | 280 | 280 |
| F | 200 | 200 | 200 | 200 |
| M | Rp 1/2" | Rp 1/2" | Rp 1/2" | Rp 1/2" |
| Connecting pneumatic connections | Øe 10mm x Øi 8mm | | | |

Tab. 5.31

| DIVAL 700 | | | | |
|--------------|----|----|----|----|
| Weight [kgf] | 15 | 17 | 20 | 18 |

Tab. 5.32

5.2.2 - DIVAL 700 + LA




Fig. 5.8. Physical characteristics DIVAL 700 + LA

| Overall dimensions DIVAL 700 + LA | | | | |
|-----------------------------------|------------------|---------|---------|------------|
| Size [inches] | 1" | 1" ½ | 2" | Rp 2" x 2" |
| Nominal diameter [mm] | 25 | 40 | 50 | 50" |
| S | 183 | 223 | 254 | 152.4 |
| A | 145 | 145 | 145 | 145 |
| B | 343 | 343 | 343 | 343 |
| B1 | 433 | 433 | 433 | 433 |
| D | 280 | 280 | 280 | 280 |
| E | 215 | 215 | 215 | 215 |
| F | 200 | 200 | 200 | 200 |
| M | Rp 1/2" | Rp 1/2" | Rp 1/2" | Rp 1/2" |
| N | Rp 1/4" | Rp 1/4" | Rp 1/4" | Rp 1/4" |
| Connecting pneumatic connections | Øe 10mm x Øi 8mm | | | |

Tab. 5.33

| DIVAL 700 + LA | | | | |
|----------------|----|----|----|----|
| Weight [kgf] | 16 | 18 | 21 | 19 |

Tab. 5.34

5.3 - EQUIPMENT ANCHORING AND LIFTING METHOD

 **HAZARD!**

Before moving the equipment, make sure that the capacity of the lifting equipment is suitable for the load.

 **WARNING!**

Unloading, transport and handling activities must be carried out by operators qualified and specially trained:

- on accident prevention rules;
- on maximum safety in the workplace;
- on the use of lifting equipment.

 **ATTENTION!**

Before moving the equipment:

- remove any movable or hanging component or firmly secure it to the load;
- protect fragile equipment;
- check that the load is stable.

5.3.1 - FORKLIFT HANDLING METHOD

HAZARD!

It is forbidden to:

- Do not transit under suspended loads;
- Do not move the load over the personnel operating in the site/plant area.

WARNING!





The following is not allowed on forklifts:


- carrying passengers;
- lifting people.

NOTICE!

Packaging must always be handled in a vertical position

Proceed as described at "Tab. 5.35":

| Step | Action | Image |
|------|--|--|
| 1 | Place the forks of the forklift under the load surface. | <p>1</p>  |
| 2 | Make sure that the forks protrude from the front of the load (by at least 5 cm), far enough to eliminate any risk of the transported load tipping. | <p>2</p>  |
| 3 | <p>Raise the forks until they are touching the load.</p> <div style="border: 1px solid blue; padding: 5px; margin-top: 10px;"> <p>NOTICE! Fasten the load to the forks with clamps or similar devices if required.</p> </div> | <p>3</p>  |
| 4 | Slowly lift the load by a few dozen centimetres and check its stability, making sure that the centre of gravity of the load is positioned at the centre of the lifting forks. | <p>4</p>  |

| Step | Action | Image |
|------|--|---|
| 5 | Tilt the mast backwards (towards the driver's seat) to help the over-turning moment and to ensure greater load stability during transport. |  |
| 6 | Adjust transport speed according to the type of floor and load, avoiding sudden manoeuvres. ⚠ WARNING! In case of: <ul style="list-style-type: none"> • obstacles along the path; • particular operating situations; hinder operator visibility, the assistance of a ground operator is required, standing outside the range of action of the lifting equipment, with the task of signalling. | - |
| 7 | Place the load in the chosen installation area. | - |

Tab. 5.35

5.3.2 - CRANE HANDLING METHOD

⚠ WARNING!

It is mandatory to use CE marked chains, ropes and eyebolts or marked with conformity marks/markings in accordance with the regulations in force in the place of installation. Do not use chains connected to each other by bolts.

Always check that:

- the safety catch of the hook returns to the initial position;
- the ropes are in excellent condition and have adequate sections.


It is forbidden to:

- drag the load on the ground;
- operate near power lines;
- stand within the range of action of the crane.

! NOTICE!


Packaging must be always handled in a vertical position.

The equipment must be handled using the lifting points provided on the equipment itself. For proper transport, follow the procedure in "Tab. 5.36":

| Step | Action | Image |
|------|--|--|
| 1 | Attach the lifting rope or chain to the appropriate supports. ⚠ WARNING! The lifting point is sized for lifting only the equipment, and not other parts of the system connected to it. |  |
| 2 | Slightly lift the load making sure the ropes or chains are secure. ! NOTICE! Check whether the load is properly balanced. | |
| 3 | Handle the load avoiding sudden movements. | |
| 4 | Place the load in the chosen installation area. | |


Tab. 5.36

5.4 - PACKAGING REMOVAL

| Packaging removal | |
|-------------------------------|--|
| Operator qualification | <ul style="list-style-type: none"> Person in charge of transport, handling, unloading and placing on site; Installer. |
| PPE required | <div style="display: flex; align-items: center;">  </div> <div style="background-color: #f4a460; padding: 5px; margin-top: 10px;"> <p>⚠ WARNING!</p> </div> <p>The PPE listed in this table is related to the risk associated with the equipment. For the PPE necessary to protect against risks associated with the workplace or operating conditions, please refer to:</p> <ul style="list-style-type: none"> the regulations in force in the country of installation; <u>any information provided by the Safety Manager at the installation facility.</u> |

Tab. 5.37

To unpack the equipment in a cardboard box, proceed as described in “Tab. 5.38”:

| Step | Action | Image |
|------|---|--|
| 1 | Remove the straps (A). |  |
| 2 | Remove the packaging cardboard (B). | |
| 3 | Remove the fasteners that secure the equipment to the base (if any). | |
| 4 | Move the equipment from the base to the place intended for it. <div style="border: 1px solid blue; padding: 5px; margin-top: 10px;"> <p>⚠ NOTICE!</p> <p>Have at least 2 operators manually move the equipment, if required due to its dimensions/weight.</p> </div> | |

Tab. 5.38

⚠ NOTICE!

After removing all packaging materials, check for any anomalies.

If there are anomalies:

- do not install the equipment;
- contact PIETRO FIORENTINI S.p.A. and specify the details provided on the equipment nameplate.


5.4.1 - PACKAGING DISPOSAL

⚠ NOTICE!

Sort the various materials making up the packaging and dispose of them in compliance with the regulations in force in the country of installation.

5.5 - STORAGE AND ENVIRONMENTAL CONDITIONS

If the equipment needs to be stored for an extended period, the minimum environmental conditions for the intended storage are provided. Only by complying with these requirements can the declared performance be guaranteed:


| Conditions | Data |
|------------------------|---|
| Maximum storage period | Maximum 3 years. <div style="border: 1px solid black; padding: 5px;">  NOTICE! For installations in later periods, see paragraph “5.5.1 - Pre-installation warnings after prolonged storage”. </div> |
| Temperature | Not above 40°C |
| Humidity | Not above 70% |
| Radiation | Away from radiation sources according to UNI ISO 2230:2009 |

Tab. 5.39

5.5.1 - PRE-INSTALLATION WARNINGS AFTER PROLONGED STORAGE

For installations that have been stored for longer than 3 years, the condition of all rubber parts must be checked and, if found to be damaged, they must be replaced in order to ensure the correct functioning of the equipment.

For the replacement of the rubber parts of the equipment, please refer to “9 - Maintenance and functional checks”.

| |
|---|
| <div style="border: 1px solid black; padding: 5px;">  NOTICE! PIETRO FIORENTINI S.p.A. recommends checking the condition of rubber parts in case of downtime or storage longer than 3 years. </div> |
|---|

6 - INSTALLATION

6.1 - INSTALLATION PRE-REQUISITES

6.1.1 - ALLOWED ENVIRONMENTAL CONDITIONS

WARNING!

To safely use the equipment, in full respect of the allowed environmental conditions, follow the data shown on the regulator plate and on any accessories (refer to paragraph “2.8 - Applied rating plates”).

The installation site must be suitable for the safe use of the equipment.

The installation area of the equipment must be properly lit to ensure proper operator visibility during working on the equipment.

NOTICE!

The equipment must operate in places that are properly lit by artificial lighting suitable for the protection of the operator (in compliance with UNI EN 12464-1:2011 and UNI EN 12464-2:2014). If maintenance work is to be performed in areas and/or parts that are poorly lit, it is mandatory to:

- use all the light sources of the installation plant;
- be equipped with a handheld lighting system or connected to the power mains, compliant with Directive 2014/34/EU (ATEX) for use in environments at risk of explosion.

6.1.2 - CHECKS BEFORE INSTALLATION

The equipment does not require any further upstream safety device for protection against any overpressure with respect to its **PS admissible pressure** when, for the upstream reduction station, the maximum incidental downstream pressure is:

$$\text{MIPd} \leq 1.1 \text{ PS}$$

MIPd = Maximum incidental downstream pressure value (for further information, see UNI EN 12186:2014).

ATTENTION!

If the installation of the equipment requires the application of compression fittings, these must be installed in accordance with the instructions of the Manufacturer of the fittings themselves.



The choice of fittings must be compatible with:

- **the use specified for the equipment;**
- **the plant specifications when required.**

Before installation, it must be ensured that:

- the expected dimensions of the installation site are compatible with those of the equipment;
- there are no impediments for the workers in charge of maintenance;
- the upstream and downstream pipes are at the same level and can bear the weight of the equipment;
- the inlet and outlet connections of the pipes are aligned on the flanges;
- the inlet and outlet connections of the equipment are clean and flawless;
- the inside of the upstream pipe is clean and free of processing residues such as welding slag, sand, paint residues, water, etc...

Installation

| | |
|-------------------------------|--|
| Operator qualification | Installer |
| PPE required |  <p> WARNING!</p> <p>The PPE listed in this table is related to the risk associated with the equipment. For the PPE required to protect against risks associated with the workplace, installation or operating conditions, please refer to:</p> <ul style="list-style-type: none"> • the regulations in force in the country of installation; • any information provided by the Safety Manager at the installation facility. |
| Equipment required | Please refer to the chapter "7 - Commissioning/maintenance equipment". |

Tab. 6.40

6.2 - SPECIFIC SAFETY INSTRUCTIONS FOR THE INSTALLATION STEP

 **WARNING!**

Before proceeding with installation, make sure that the upstream and downstream valves installed on the line are shut off.

 **WARNING!**

Installation may also take place in areas where there is a risk of explosion, which implies that all necessary prevention and protection measures have to be taken.

For these measures, please refer to the regulations in force at the place of installation.

6.3 - GENERAL INFORMATION ON CONNECTIONS

The equipment must be installed in-line with an arrow on the body pointing to the gas flow direction.
In line installation, there must be (see Fig. 6.9 and 6.10):

| Pos. | Description |
|------|--|
| 1 | 1 shut-off valve upstream of the equipment. |
| 2 | 2 vent valves one upstream and one downstream of the equipment. |
| 3 | 2 pressure gauges one upstream and one downstream of the equipment. |
| 4 | 1 pressure regulator . |
| 5 | 1 shut-off valve downstream of the equipment. |

Tab. 6.41




Fig. 6.9. In-line installation




Fig. 6.10. Angle installation

! NOTICE!

When used in gas pressure reduction stations, the device must be installed at least according to the requirements of standards UNI EN 12186:2014 or UNI EN 12279:2007.

Equipment vents must be ducted in accordance with UNI EN 12186:2014 or UNI EN 12279:2007 or the standards in force at the place of installation of the equipment.

6.4 - REGULATOR INSTALLATION POSITIONS

Figure 6.11 and 6.12 illustrate typical regulator arrangements:




Fig. 6.11. Standard position




Fig. 6.12. Inverted position

6.5 - INSTALLATION PROCEDURES

6.5.1 - EQUIPMENT INSTALLATION PROCEDURES

| Step | Action |
|------|--|
| 1 | Place the equipment in the section of the line designated for it. |
| 2 | Place the gaskets between the line flanges and the regulator flanges. |
| 3 | Insert the bolts into the appropriate holes of the connecting flanges. |
| 4 | Screw the bolts following the technical rules for tightening flanges. |

Tab. 6.42

NOTICE!

For installation after maintenance, replace the seals.

6.5.2 - CONNECTION OF THE SENSING LINES TO THE DOWNSTREAM PIPING

For the Dival 700 equipment the sensing lines are internal (Fig. 6.13), for the Dival 700 with inline monitor function the sensing lines are external (Fig. 6.14).




Fig. 6.13. Connection of sensing lines to the downstream piping DIVAL 700




Fig. 6.14. Sensing line connection to downstream pipeline DIVAL 700 with monitor function

For proper adjustment, it is essential that:

- the downstream shut-off valve is placed at a distance of at least 6 times the nominal diameter of the pipe downstream of the regulator;
- the downstream sensing lines are placed on a straight section of pipe (with uniform diameter) having a length equal to at least 4 times the rated diameter of the pipe itself;
- the velocity of the pressurised fluid at the sampling point does not exceed the following values:

$V_{max} = 30 \text{ m/s}$ for $P_a > 5 \text{ bar}$

$V_{max} = 25 \text{ m/s}$ per $P_a < 5 \text{ bar}$

To calculate the flow rate, use the following formula:

$$V = 345,92 \times \frac{Q}{DN^2} \times \frac{1 - 0,002 \times Pd}{1 + Pd}$$

V = gas velocity in m/sec

Q = gas flow rate Sm^3/h

DN = nominal pipe diameter in mm

Dp = regulator outlet pressure in barg

! NOTICE!

All on-site pneumatic connections must have pipes with a minimum internal diameter of 8 mm.

To prevent the pneumatic connections of the sensing lines from collecting impurities and condensation, it is necessary that:

- the connections of the pneumatic connection are always welded to the top or horizontal axis of the pipe itself (refer to Fig. 6.14);
- the hole in the piping has no burrs or internal protrusions;
- the slope of the pneumatic connection is always 5-10% towards the downstream pipe connection.




Fig. 6.15. Welded pipe connections

If there is a multiple sensing line, connect the equipment connections as shown below:

- 1 and 2 to the discharge outlet of the regulator control head and of the regulator in monitor function (when present);
- 3 and 4 free sensing lines;
- 5 and 6 to the sensing lines of the slam-shut valve (when present).

! NOTICE!

If there is a multiple sensing line, it is not recommended to place shut-off valves on sensing lines. In any case, follow the regulations in force in the place of installation and use of the equipment.




Fig. 6.16. Equipment connections


6.6 - POST-INSTALLATION AND PRE-COMMISSIONING CHECKS

When the equipment is operating, make sure that all connections are:

- properly secured/tightened to prevent any leakage during commissioning;
- connected correctly.







7 - COMMISSIONING/MAINTENANCE EQUIPMENT










7.1 - LIST OF EQUIPMENT

| Use of commissioning/maintenance equipment | |
|--|---|
| Operator qualification | <ul style="list-style-type: none"> • Mechanical maintenance technician; • Electrical maintenance technician; • Installer; • Name of the user. |
| PPE required | <div style="display: flex; align-items: center;">  </div> <div style="background-color: #f4a460; padding: 5px; margin-top: 5px;"> <p>⚠ WARNING!</p> </div> <p>The PPE listed in this table is related to the risk associated with the equipment. For the PPE required to protect against risks associated with the workplace, installation or operating conditions, please refer to:</p> <ul style="list-style-type: none"> • the regulations in force in the country of installation; • any information provided by the Safety Manager at the installation facility. |

Tab. 7.43

The types of equipment required to commission and service the equipment are described in “Tab. 7.44”:

| Ref. | Equipment type | Image |
|----------|---|---|
| A | Combination wrench |  |
| B | Adjustable wrench |  |
| C | Roller compass spanner |  |
| D | Double ended bi-hex tubular socket wrench |  |
| E | Bent male hex key |  |
| F | Male T-handle hex wrench |  |

| Ref. | Equipment type | Image |
|----------|----------------------------|---|
| G | T-handle hex socket wrench |  |
| H | Phillips screwdriver |  |
| I | Slotted screwdriver |  |
| L | O-ring extraction tool |  |
| M | Circlip pliers |  |
| N | Fiorentini special key |  |
| O | Fiorentini special key |  |
| P | Fiorentini special tool |  |
| Q | Torx key |  |

Tab. 7.44

7.2 - EQUIPMENT NEEDED FOR THE DIFFERENT CONFIGURATIONS

Each table is distinguished by:

| Term | Description |
|---------------|--|
| K./Wr. | Key, with reference to the equipment indicated in "Tab. 7.44". |
| Code | Code, referring to the equipment. |
| DN | Indicates the Nominal Diameter of the reference configuration. |
| L. | Length, referred to the equipment. |
| Ref. | Reference to the equipment. |
| Type | Type (size) or code of the equipment. |

Tab. 7.45

DIVAL 700 | REGULATOR WITH IN LINE MONITOR FUNCTION

| Equipment | | Size [inches] DN [mm] | | |
|-----------|--------|-----------------------------|-----------|---------|
| Ref. | Type | 1" 25 | 1" ½ 40 | 2" 50 |
| A | K./Wr. | 10 - 12 - 13 - 17 - 22 - 24 | | |
| D | K./Wr. | 24 - 26 - 27 - 36 - 46 | | |
| E | K./Wr. | 19 | | |
| F | K./Wr. | 3 - 4 - 5 - 6 - 8 | | |
| G | K./Wr. | 7 - 8 - 10 | | |

Tab. 7.46

DIVAL 700 + LA

| Equipment | | Size [inches] DN [mm] | | |
|-----------|--------|-----------------------------|-----------|---------|
| Ref. | Type | 1" 25 | 1" ½ 40 | 2" 50 |
| A | K./Wr. | 10 - 12 - 13 - 17 - 22 - 24 | | |
| D | K./Wr. | 24 - 26 - 27 - 36 - 46 | | |
| E | K./Wr. | 19 | | |
| F | K./Wr. | 3 - 4 - 5 - 6 - 8 | | |
| G | K./Wr. | 7 - 8 - 10 | | |
| Q | Type | T 20 | | |

Tab. 7.47

8 - COMMISSIONING

8.1 - GENERAL WARNINGS

8.1.1 - SAFETY REQUIREMENTS FOR COMMISSIONING

HAZARD!

During commissioning the risks associated with any discharges to the atmosphere of flammable or noxious gases must be evaluated.

HAZARD!

In case of installation on distribution networks for natural gas, consider the risk associated with explosive mixtures (gas/air) being formed inside the piping, if the line is not subjected to inerting.

WARNING!

During commissioning, any unauthorised personnel must keep away.
The no entry area has to be marked with signs and/or boundaries.

NOTICE!

Commissioning has to be carried out by authorised and qualified personnel.

The equipment and accessories (regulator with in-line monitor function, LA incorporated slam-shut valve) are supplied already calibrated.



NOTICE!

It is possible that for various reasons (e.g. vibrations during transport) the calibration of the equipment's accessories may vary, although within the values indicated on the identification plates.

Before commissioning the equipment, it is necessary to check that:

- all shut-off valves (inlet, outlet, any bypass) are closed;
- the gas is at a temperature within the limits specified on the data plate.

Commissioning

| | |
|-------------------------------|---|
| Operator qualification | <ul style="list-style-type: none"> • Installer; • Qualified technician. |
| PPE required |  <p> WARNING!</p> <p>The PPE listed in this table is related to the risk associated with the equipment. For the PPE required to protect against risks associated with the workplace, installation or operating conditions, please refer to:</p> <ul style="list-style-type: none"> • the regulations in force in the country of installation; • any information provided by the Safety Manager at the installation facility. |
| Equipment required | Please refer to the chapter "7 - Commissioning/maintenance equipment". |

Tab. 8.48

8.2 - PRELIMINARY PROCEDURES FOR COMMISSIONING

HAZARD!

Before commissioning the equipment, it must be ensured that any source of explosion has been eliminated if there is such a danger.

WARNING!

Before commissioning, you need to make sure that the characteristics of the equipment are suitable for the conditions of use.


ATTENTION!

To protect the equipment from damage, never:

- pressurise the equipment through a valve located downstream of it;
- depressurise the equipment through a valve located upstream of it.

Commissioning can be carried out using two different procedures:

Commissioning types

| | |
|------------------------------------|--|
| Injection of an inert fluid | Pressurising the equipment by injecting an inert fluid (e.g. nitrogen) to avoid potentially explosive mixtures for services with combustible gases. <div style="background-color: #f4a460; padding: 5px; margin-top: 5px;">  WARNING! During pressurisation, always check that the equipment has no leaks. </div> |
| Direct injection | Direct injection of gas into pipes, keeping the gas velocity in the pipes as low as possible (maximum permitted value of 5 m/s). |

Tab. 8.49

8.3 - PROPER COMMISSIONING CHECK

Completely sprinkle the equipment with a foaming solution (or equivalent control system) in order to check the tightness of the external surfaces of the regulator and the connections made during the installation.

8.4 - CALIBRATION OF EQUIPMENT AND ACCESSORIES INSTALLED

 **NOTICE!**

To properly calibrate the equipment and accessories present, refer to the accuracy class indicated on the nameplates (see section “2.8 - Applied rating plates”).

8.5 - REGULATOR COMMISSIONING PROCEDURE

In the application consisting of two pressure adjusting lines, it is advisable to commission one line at a time, starting with the line with the lowest set point.

The set point value is mentioned on the test certificate enclosed with each piece of equipment.




Fig. 8.17. Commissioning the DIVAL 700 regulator

| Step | Action |
|------|--|
| 1 | Partially open the bleed cock (6). |
| 2 | <p>Partially open the upstream shut-off valve (V1), checking that the downstream pressure (Pd) indicated on the downstream pressure gauge (5) does not exceed the required calibration value by over 50%.</p> <p>! NOTICE!</p> <p>In the first line pressurisation phase, the downstream pressure (Pd) indicated on the downstream pressure gauge (5) could exceed that required calibration value, depending on the response time of the regulator.</p> <p>! NOTICE!</p> <p>With regulators with calibration pressure up to 80 mbar, the response time is longer than that of regulators with calibration pressure above 80 mbar.</p> |
| 3 | When the regulator is put into service, the downstream pressure (Pd) indicated on the downstream pressure gauge (5) will be equal to the calibration value of the regulator. |
| 4 | <p>a - FOR INITIAL COMMISSIONING OF THE REGULATION LINE</p> <p>If the pressure downstream (Pd) is not at the required calibration value, proceed as follows:</p> <ul style="list-style-type: none"> • downstream pressure value (Pd) lower than required calibration value: load the setting spring by turning the adjustment ring nut clockwise (3) • downstream pressure value (Pd) higher than required calibration value: load the setting spring by turning the adjustment ring nut anti-clockwise (3) <p>b - AFTER MAINTENANCE OF THE REGULATION LINE</p> <ul style="list-style-type: none"> • load the setting spring (328) and increase the pressure value of the main regulator (1) by turning the adjustment ring nut clockwise (3) |
| 5 | Check the downstream pressure (Pd) referring to the downstream pressure gauge (5). |
| 6 | Close the bleed cock (6). |
| 7 | <p>Check that the downstream pressure (Pd), after an increment phase, does not exceed the closing pressure value (refer to the SG value displayed on the plate, see par. "2.8 - Applied rating plates").</p> <p>! NOTICE!</p> <p>If the pressure in the pipe section between the regulator and the downstream shut-off valve (V2) exceeds the closing pressure value, consult chapter "10 - Troubleshooting" to clear the causes of the malfunctions.</p> |
| 8 | <p>Check the tightness of all the fittings between the shut-off valves (V1, V2).</p> <p>! NOTICE!</p> <p>Check for sealing with a foaming substance.</p> |
| 9 | In case of external leaks, eliminate the leak points and repeat the procedure from step 7. |
| 10 | <p>Open downstream shut-off valve (V2) very slowly until the pipeline fills completely.</p> <p>! NOTICE!</p> <p>If the pressure of the downstream pipeline is lower than the calibration pressure, partially open the downstream shut-off valve (V2) so as to not to exceed the maximum flow rate value of the installation.</p> |

Tab. 8.50

8.6 - COMMISSIONING PROCEDURE OF REGULATION LINE: DIVAL 700 REGULATOR + DIVAL 700 REGULATOR WITH IN LINE MONITOR FUNCTION

NOTICE!

VALID FOR REGULATORS WITH DOWNSTREAM PRESSURE UP TO 80mbar

The setting spring (328.1) of the main regulator (1) must allow you to obtain the downstream pressure value (Pd) 10-20% higher than the calibration pressure value of the regulator with in-line monitor function (2).





Fig. 8.18. Commissioning of DIVAL 700 regulator + regulator with in-line monitor function

| Step | Action |
|------|---|
| 1 | Partially open the bleed cock (6). |
| 2 | <p>Partially open the upstream shut-off valve (V1), checking that the downstream pressure (Pd) indicated on the downstream pressure gauge (5) does not exceed the required calibration value by over 50%.</p> <p>! NOTICE!</p> <p>In the first line pressurisation phase, the downstream pressure (Pd) indicated on the downstream pressure gauge (5) could exceed that required calibration value, depending on the response time of the main regulator (1).</p> <p>! NOTICE!</p> <p>With regulators with calibration pressure up to 80 mbar, the response time is longer than that of regulators with calibration pressure above 80 mbar.</p> |
| 3 | When the main regulator (1) is put into service, the downstream pressure (Pd) indicated on the downstream pressure gauge (5) will be equal to the calibration value of the main regulator (1). |
| 4 | <p>Check that the regulator with in-line monitor function (2) is fully open (100%).</p> <p>! NOTICE!</p> <p>The regulator with monitor function (2) is fully open, when the pressure indicated on the intermediate pressure gauge (4) is the same as the upstream pressure gauge (8).</p> |
| 5 | Open the upstream shut-off valve (V1) completely. |
| 6 | <p>Increase the downstream pressure value (Pd) beyond the calibration pressure of the regulator with monitor function (2), by turning the adjustment ring nut (3) of the main regulator (1) clockwise.</p> <p>! NOTICE!</p> <p>If the setting spring of the main regulator (1) does not reach a sufficient pressure to trip the regulator with in-line monitor function (2), pressurise the chamber (A) by using an external source (see par. "8.6.1 - Pressurising with external source").</p> <p>! NOTICE!</p> <p>The value of the pressure introduced by the external source can be up to 50% more than the calibration value of the regulator with in-line monitor function (2).</p> |
| 7 | Check that the regulator with in-line monitor function (2) is running, checking that the pressure indicated on the intermediate pressure gauge (4) is comparable to the calibration value of the regulator with in-line monitor function (2). |
| 8 | <p>a - FOR INITIAL COMMISSIONING OF THE REGULATION LINE</p> <p>If the downstream pressure (Pd) is not at the required calibration value for the regulator with in-line monitor function (2), proceed as follows:</p> <ul style="list-style-type: none"> • downstream pressure value (Pd) lower than required calibration value: load the setting spring by turning the adjustment ring nut clockwise (9) • downstream pressure value (Pd) higher than required calibration value: load the setting spring by turning the adjustment ring nut anti-clockwise (9) <p>b - AFTER MAINTENANCE OF THE REGULATION LINE</p> <ul style="list-style-type: none"> • load the setting spring (328.2) and increase the pressure value of the regulator with monitor function (2) by turning the adjustment ring nut clockwise (9) |
| 9 | <p>Check the calibration value of the regulator with in-line monitor function (2), referring to the downstream pressure gauge (5).</p> <p>! NOTICE!</p> <p>If the calibration pressure is not as pre-established, repeat steps 8a (first commissioning) or 8b (after maintenance).</p> |



Commissioning of DIVAL 700 regulator + regulator with in-line monitor function

| Step | Action |
|------|--|
| 10 | Slowly close the bleed cock (6). |
| 11 | <p>Check that the downstream pressure, after an increment phase, does not exceed the closing pressure value of the regulator with in-line monitor function (2) (refer to the SG value displayed on the plate, see par. “2.8 - Applied rating plates”).</p> <div style="border: 1px solid black; padding: 5px;"> <p>! NOTICE!</p> <ul style="list-style-type: none"> • If the downstream pressure exceeds the closing pressure value, refer to chapter “10 - Troubleshooting” to clear the causes of the malfunctions. • Check the pressure referring to the downstream pressure gauge (5). </div> |
| 12 | Partially open the bleed cock (6). |
| 13 | Discharge the regulation spring of the main regulator (1) or disconnect the external pressure source from the chamber (A). |
| 14 | <p>Check that the regulator with in-line monitor function (2) is fully open (100%).</p> <div style="border: 1px solid black; padding: 5px;"> <p>! NOTICE!</p> <p>The regulator with in-line monitor function (2) is fully open, when the pressure indicated on the intermediate pressure gauge (4) is the same as the upstream pressure gauge (8).</p> </div> |
| 15 | Check that the calibration pressure of the main regulator (1) is as pre-established by referring to the pressure value indicated on the downstream pressure gauge (5). |
| 16 | <p>a - FOR INITIAL COMMISSIONING OF THE REGULATION LINE</p> <p>If the pressure downstream (Pd) is not at the required calibration value, proceed as follows:</p> <ul style="list-style-type: none"> • downstream pressure value (Pd) lower than required calibration value: load the setting spring by turning the adjustment ring nut clockwise (3) • downstream pressure value (Pd) higher than required calibration value: load the setting spring by turning the adjustment ring nut anti-clockwise (3) <p>b - AFTER MAINTENANCE OF THE REGULATION LINE</p> <ul style="list-style-type: none"> • load the setting spring (328.1) and increase the pressure value of the main regulator (1) by turning the adjustment ring nut clockwise (3) |
| 17 | Slowly close the bleed cock (6). |

| Step | Action |
|------|---|
| 18 | <p>Check that the downstream pressure, after an increment phase, does not exceed the closing pressure value of the main regulator (1) (refer to the SG value displayed on the plate, see par. "2.8 - Applied rating plates").</p> <div style="border: 1px solid black; padding: 5px;"> <p>! NOTICE!</p> <ul style="list-style-type: none"> • If the downstream pressure exceeds the closing pressure value, refer to chapter "10 - Troubleshooting" to clear the causes of the malfunctions. • Check the pressure referring to the downstream pressure gauge (5). </div> |
| 19 | Using a foaming agent, check all the joints between shut-off valves (V1, V2) for proper sealing. |
| 20 | In case of external leaks, eliminate the leak points and repeat the procedure from step 1. |
| 21 | <p>Slowly open the downstream shut-off valve V2 until the piping has been completely filled.</p> <div style="border: 1px solid black; padding: 5px;"> <p>! NOTICE!</p> <ul style="list-style-type: none"> • If the pressure of the downstream pipeline is lower than the calibration pressure, partially open the downstream shut-off valve (V2) so as to not to exceed the maximum flow rate value of the installation. • Check the pressure referring to the downstream pressure gauge (5). </div> |

Tab. 8.51

8.6.1 - PRESSURISING WITH EXTERNAL SOURCE

If the setting spring of the main regulator (1) does not reach a sufficient pressure to put into service the regulator with in-line monitor function (2), you may pressurise the chamber (A) of the control head of the main regulator (1) by using an external source.

Pressurisation can be done:

- with external lines;
- manually.

The introduced pressure is controlled by using pressure gauges or transducers.

To correctly discharge the introduced pressure, make sure there is an additional bleed cock (18).




Fig. 8.19. Pressurising with external source (hand pump)

8.7 - COMMISSIONING PROCEDURE OF DIVAL 700 REGULATOR WITH LA SLAM-SHUT VALVE

8.7.1 - INTERNAL TIGHTNESS CHECK OF LA SLAM-SHUT VALVE




Fig. 8.20. Commissioning of the regulator DIVAL 700 with LA slam-shut valve


| Step | Action |
|------|--|
| 1 | Check that the slam-shut valve is in the shut-off position. |
| 2 | Open the bleed cock (6) to fully discharge the downstream section. |
| 3 | Slowly open the upstream shut-off valve (V1). |
| 4 | Check the internal tightness of the slam-shut valve by means of the bleed cock (6). <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>! NOTICE!</p> <ul style="list-style-type: none"> • Check the seal with a foaming substance; • In case of leaks, please refer to the chapter “10 - Troubleshooting” to clear the causes of malfunctions. </div> |

Tab. 8.52

8.7.2 - COMMISSIONING OF THE DIVAL 700 REGULATOR WITH LA SLAM-SHUT VALVE

For the following procedure, please refer to Fig. 8.20 at “8.7.1 - Internal tightness check of LA slam-shut valve”:

| Step | Action |
|------|---|
| 1 | Make sure that the bleed cock (6) is partially open. |
| 2 | Check that the LA slam-shut valve is in the shut-off position. ! NOTICE! If the LA slam-shut valve is in the open position, close it using the manual button (fig. 8.20, ref. 10). |
| 3 | Partially open the upstream shut-off valve (V1), checking the pressure indicated by the upstream pressure gauge (4). |
| 4 | Perform the internal tightness check of the LA slam-shut valve, referring to chapter “8.7.1 - Internal tightness check of LA slam-shut valve”. ! NOTICE! In case of leaks, please refer to the chapter “10 - Troubleshooting” to clear the causes of malfunctions. |
| 5 | Slowly pressurise the control line, acting on the knob of the LA slam-shut valve (refer to the "Operation" section at 4.5.4.1), checking that the downstream pressure (Pd) indicated by the downstream pressure gauge (5) does not exceed the required setting value by more than 50%. |
| 6 | When the regulator is put into service, the pressure on the downstream pressure gauge (5) will be equal to the calibration value of the main regulator. ! NOTICE! In the first line pressurisation phase, the pressure on the downstream pressure gauge (5) could exceed the required calibration value, depending on the response time of the regulator. |
| 7 | Open the upstream shut-off valve (V1) completely. |
| 8 | Check calibrations of the pressure switch of the LA slam-shut valve by referring to paragraph “8.7.3 - Procedure for calibrating the pressure switch for the LA incorporated slam-shut valve”. |
| 9 | a - FOR INITIAL COMMISSIONING OF THE REGULATION LINE If the pressure downstream (Pd) is not at the required calibration value, proceed as follows: <ul style="list-style-type: none"> downstream pressure value (Pd) lower than required calibration value: load the setting spring by turning the adjustment ring nut clockwise (3) downstream pressure value (Pd) higher than required calibration value: load the setting spring by turning the adjustment ring nut anti-clockwise (3) b - AFTER MAINTENANCE OF THE REGULATION LINE <ul style="list-style-type: none"> load the setting spring (328) and increase the pressure value of the regulator (1) by turning the adjustment ring nut clockwise (3) |
| 10 | Check the downstream pressure (Pd) referring to the downstream pressure gauge (5). |
| 11 | Close the bleed cock (6). |



Commissioning of the DIVAL 700 regulator with LA slam-shut valve

| Step | Action |
|------|--|
| 12 | <p>Check that the downstream pressure (P_d), after an increment phase, does not exceed the closing pressure value (refer to the SG value displayed on the plate, see par."2.8 - Applied rating plates").</p> <p>! NOTICE!</p> <p>If the pressure in the pipe section between the regulator and the downstream shut-off valve (V2) exceeds the closing pressure value, consult chapter "10 - Troubleshooting" to clear the causes of the malfunctions.</p> |
| 13 | <p>Check the tightness of all the fittings between the shut-off valves (V1, V2).</p> <p>! NOTICE!</p> <p>Check for sealing with a foaming substance.</p> |
| 14 | <p>If external leaks are noticed, eliminate the leak points and repeat the procedure from step 7.</p> |
| 15 | <p>Open downstream shut-off valve (V2) very slowly until the pipeline fills completely.</p> <p>! NOTICE!</p> <p>If the pressure of the downstream pipeline is lower than the calibration pressure, partially open the downstream shut-off valve (V2) so as to not to exceed the maximum flow rate value of the installation.</p> |

Tab. 8.53

8.7.3 - PROCEDURE FOR CALIBRATING THE PRESSURE SWITCH FOR THE LA INCORPORATED SLAM-SHUT VALVE




Fig. 8.21. Calibration of pressure switch for LA slam-shut valve

SPRING CALIBRATION FOR MAXIMUM PRESSURE TRIP

| Step | Action |
|------|---|
| 1 | <p>Increase the downstream pressure to the tripping value of the slam-shut valve, connecting an external pressure source to the bleed cock (fig. 8.16, ref. 6) placed on the downstream pipe, making sure to open an additional bleed cock (fig. 8.21, ref. 18).</p> <div style="border: 1px solid black; padding: 5px;"> <p>! NOTICE!</p> <p>Check the pressure referring to the downstream pressure gauge (fig. 8.16, ref. 5).</p> <p>If the slam-shut valve:</p> <ul style="list-style-type: none"> • trips before the expected pressure value: screw in (clockwise) the adjustment ring nut (13) so as to further compress the spring (11); • does not trip at the expected pressure value: unscrew (anti-clockwise) the adjustment ring nut (13) so as to relieve the spring (11). </div> |
| 2 | Decrease the pressure of the downstream section by opening the additional bleed cock (21, ref. 18) to bring it up to the calibration value of the main regulator. |
| 3 | Close the additional bleed cock (fig. 8.21, ref. 18). |
| 4 | Resetting the slam-shut valve by turning the reset knob (16). |
| 5 | Repeat steps 1-2-3-4 at least three times, observing the operating limits indicated on the nameplate. |
| 6 | Disconnect the external pressure source from the bleed cock (fig. 8.16, ref. 6). |

Tab. 8.54




Fig. 8.20. Calibration of pressure switch for LA slam-shut valve




Fig. 8.22. Pressurising with external source for incorporated LA slam-shut valve

SPRING CALIBRATION FOR MINIMUM PRESSURE TRIP (IF PRESENT)

| Step | Action |
|------|---|
| 1 | Partially open the bleed cock (fig. 8.16, ref. 6) to the atmosphere and keep it open for the next steps. |
| 2 | Turn the adjustment ring nut (fig. 8.16, ref. 3) of the regulator anti-clockwise to decrease the downstream pressure (Pd) to the minimum pressure required for tripping of the slam-shut valve. |
| 3 | <p>If necessary, remove the closing cap (fig. 8.21, ref. 354) together with the adjustment ring nut and remove the regulation spring (fig. 8.21, ref. 328).</p> <div style="border: 1px solid blue; padding: 5px;"> <p>! NOTICE!</p> <p>Check the tripping pressure value of the slam-shut valve indicated on the downstream pressure gauge (fig. 8.19, ref. 5).</p> </div> |
| 4 | <p>If the slam-shut valve:</p> <ul style="list-style-type: none"> trips before the expected pressure value, unscrew (anticlockwise) the adjustment ring nut (fig. 8.20, ref. 15), to relieve the spring (fig. 8.20, ref. 17); does not trip at the expected pressure value, screw in (clockwise) the adjustment ring nut (fig. 8.20, ref. 15) to further compress the spring (fig. 8.20, ref. 17). |
| 5 | <p>After having checked that the slam-shut valve trips at the preset value, proceed as follows:</p> <ol style="list-style-type: none"> Close the air vent valve (fig. 8.16, ref. 6) Position the regulation spring (fig. 8.21, ref. 328), the closing cap (fig. 8.21, ref. 354), and adjustment ring nut (fig. 8.16, ref. 3) Slowly open the upstream shut-off valve (V1) until the downstream pressure value (Pd) reaches the calibration value of the regulator, referring to the downstream pressure gauge (fig. 8.16, ref. 5) Close the upstream shut-off valve (V1) Slowly and partially open the air vent valve (fig. 8.16, ref. 6) to decrease the downstream pressure referring to the downstream pressure gauge (fig. 8.16, ref. 5) until it reaches the minimum pressure tripping value Check the minimum pressure spring for proper calibration by repeating steps 2-3-4 at least three times Calibrate the main regulator referring to par. "8.5 - Regulator commissioning procedure" |
| 6 | Open the slam-shut valve by acting on the reset knob (fig. 8.20, ref. 16) and keep it open manually. |
| 7 | Turn the adjustment ring nut clockwise (fig. 8.16, ref. 3) to increase the downstream pressure to the regulator's setpoint. |
| 8 | Set the slam-shut valve by acting on the reset knob (fig. 8.20, ref. 16). |
| 9 | Close the bleed cock (fig. 8.16, ref. 6). |

Tab. 8.55

COMMISSIONING THE REGULATOR

! NOTICE!

Please refer to "8.5 - Regulator commissioning procedure" of this chapter.

8.8 - COMMISSIONING PROCEDURE OF REGULATION LINE: DIVAL 700 REGULATOR + DIVAL 700 REGULATOR WITH IN LINE MONITOR + LA SLAM-SHUT VALVE FUNCTION





Fig. 8.23. Commissioning of DIVAL 700 regulator + regulator-monitor + LA

| Step | Action |
|------|--|
| 1 | Make sure that the bleed cock (6) is partially open. |
| 2 | Check that the LA slam-shut valve is in the shut-off position. NOTICE! If the LA slam-shut valve is in the open position, close it using the manual button (fig. 8.20, ref. 10). |
| 3 | Slowly open the upstream shut-off valve (V1), checking the pressure indicated by the upstream pressure gauge (4). |
| 4 | Perform the internal tightness check of the LA slam-shut valve, referring to chapter "8.7.1 - Internal tightness check of LA slam-shut valve". NOTICE! In case of leaks, please refer to the chapter "10 - Troubleshooting" to clear the causes of malfunctions. |
| 5 | Make sure that the bleed cock (6) is partially open. |
| 6 | Slowly pressurise the control line, acting on the lever of the LA slam-shut valve (refer to the "Operation" section in par. 4.5.4.1), checking that the downstream pressure (Pd) indicated by the downstream pressure gauge (5) does not exceed the required setting value by more than 50%. |
| 7 | When the regulator is put into service, the pressure on the downstream pressure gauge (5) will be equal to the calibration value of the main regulator. NOTICE! In the first line pressurisation phase, the pressure on the downstream pressure gauge (5) could exceed the required calibration value, depending on the response time of the regulator. |
| 8 | Check calibrations of the pressure switch of the LA slam-shut valve by referring to paragraph "8.7.3 - Procedure for calibrating the pressure switch for the LA incorporated slam-shut valve". |

| Step | Action |
|------|---|
| 9 | <p>! NOTICE!</p> <p>With regulators with calibration pressure up to 80 mbar, the response time is longer than that of regulators with calibration pressure above 80 mbar.</p> |
| 10 | When the main regulator (1) is put into service, the downstream pressure (Pd) indicated on the downstream pressure gauge (5) will be equal to the calibration value of the regulator (1). |
| 11 | <p>Check that the regulator with in-line monitor function (2) is fully open (100%).</p> <p>! NOTICE!</p> <p>The regulator with monitor function (2) is fully open, when the pressure indicated on the intermediate pressure gauge (4) is the same as the upstream pressure gauge (8).</p> |
| 12 | Open the upstream shut-off valve (V1) completely. |
| 13 | <p>Increase the downstream pressure value (Pd) beyond the calibration pressure of the regulator with monitor function (2), by turning the adjustment ring nut (3) of the main regulator (1) clockwise.</p> <p>! NOTICE!</p> <p>If the setting spring of the main regulator (1) does not reach a sufficient pressure to trip the regulator with in-line monitor function (2), pressurise the chamber (A) by using an external source (see par. "8.6.1 - Pressurising with external source").</p> <p>! NOTICE!</p> <p>The value of the pressure introduced by the external source can be up to 50% more than the calibration value of the regulator with in-line monitor function (2).</p> |
| 14 | Check that the regulator with in-line monitor function (2) is running, checking that the pressure indicated on the intermediate pressure gauge (4) is equal to the calibration value of the regulator with in-line monitor function (2). |
| 15 | <p>a - FOR INITIAL COMMISSIONING OF THE REGULATION LINE</p> <p>If the downstream pressure (Pd) is not at the required calibration value for the regulator with in-line monitor function (2), proceed as follows:</p> <ul style="list-style-type: none"> • downstream pressure value (Pd) lower than required calibration value: load the setting spring by turning the adjustment ring nut clockwise (9) • downstream pressure value (Pd) higher than required calibration value: load the setting spring by turning the adjustment ring nut anti-clockwise (9) <p>b - AFTER MAINTENANCE OF THE REGULATION LINE</p> <ul style="list-style-type: none"> • load the setting spring (328.2) and increase the pressure value of the regulator with in-line monitor function (2) by turning the adjustment ring nut clockwise (9) |
| 16 | <p>Check the calibration value of the regulator with in-line monitor function (2), referring to the downstream pressure gauge (5).</p> <p>! NOTICE!</p> <p>If the calibration pressure is not as pre-established, repeat steps 15a (first commissioning) or 15b (after maintenance).</p> |
| 17 | Slowly close the bleed cock (6). |



Commissioning of DIVAL 700 regulator + regulator-monitor + LA

| Step | Action |
|------|--|
| 18 | <p>Check that the downstream pressure, after an increment phase, does not exceed the closing pressure value of the regulator with in-line monitor function (2) (refer to the SG value displayed on the plate, see par. "2.8 - Applied rating plates").</p> <div style="border: 1px solid blue; padding: 5px;"> <p>! NOTICE!</p> <ul style="list-style-type: none"> • If the downstream pressure exceeds the closing pressure value, refer to chapter "10 - Troubleshooting" to clear the causes of the malfunctions. • Check the pressure referring to the downstream pressure gauge (5). </div> |
| 19 | Partially open the bleed cock (6). |
| 20 | Discharge the regulation spring (328.1) of the main regulator (1) or disconnect the external pressure source from the chamber (A) (see par. "8.6.1 - Pressurising with external source"). |
| 21 | <p>Check that the regulator with in-line monitor function (2) is fully open (100%).</p> <div style="border: 1px solid blue; padding: 5px;"> <p>! NOTICE!</p> <p>The regulator with monitor function (2) is fully open, when the pressure indicated on the intermediate pressure gauge (4) is the same as the upstream pressure gauge (8).</p> </div> |
| 22 | Check that the calibration pressure of the main regulator (1) is as pre-established by referring to the pressure value indicated on the downstream pressure gauge (5). |
| 23 | <p>a - FOR INITIAL COMMISSIONING OF THE REGULATION LINE</p> <p>If the pressure downstream (Pd) is not at the required calibration value, proceed as follows:</p> <ul style="list-style-type: none"> • downstream pressure value (Pd) lower than required calibration value: load the setting spring by turning the adjustment ring nut clockwise (3) • downstream pressure value (Pd) higher than required calibration value: load the setting spring by turning the adjustment ring nut anti-clockwise (3) <p>b - AFTER MAINTENANCE OF THE REGULATION LINE</p> <ul style="list-style-type: none"> • load the setting spring (328.1) and increase the pressure value of the main regulator (1) by turning the adjustment ring nut clockwise (3) |
| 24 | Slowly close the bleed cock (6). |

| Step | Action |
|------|---|
| 25 | <p>Check that the downstream pressure, after an increment phase, does not exceed the closing pressure value of the main regulator (1) (refer to the SG value displayed on the plate, see par. "2.8 - Applied rating plates").</p> <div style="border: 1px solid black; padding: 5px;"> <p>! NOTICE!</p> <ul style="list-style-type: none"> • If the downstream pressure exceeds the closing pressure value, refer to chapter "10 - Troubleshooting" to clear the causes of the malfunctions. • Check the pressure referring to the downstream pressure gauge (5). </div> |
| 26 | Using a foaming agent, check all the joints between shut-off valves (V1, V2) for proper sealing. |
| 27 | If external leaks are noticed, eliminate the leak points and repeat the procedure from step 10. |
| 28 | <p>Slowly open the downstream shut-off valve V2 until the piping has been completely filled.</p> <div style="border: 1px solid black; padding: 5px;"> <p>! NOTICE!</p> <ul style="list-style-type: none"> • If the pressure of the downstream pipeline is lower than the calibration pressure, partially open the downstream shut-off valve (V2) so as to not to exceed the maximum flow rate value of the installation. • Check the pressure referring to the downstream pressure gauge (5). </div> |

Tab. 8.56

COMMISSIONING OF LA SLAM-SHUT VALVE

! NOTICE!

Refer to paragraph "8.7.3 - Procedure for calibrating the pressure switch for the LA incorporated slam-shut valve".

8.11 - DEVICE CALIBRATION

8.11.1 - PRESSURE SWITCH CALIBRATION FOR THE LA SLAM-SHUT VALVE




Fig. 8.24. Pressure switch calibration for the LA slam-shut valve

Turn the ring nut (13) for maximum tripping (11):

- anti-clockwise to decrease the slam-shut device tripping pressure;
- clockwise to increase the slam-shut device tripping pressure.

Turn the ring nut (15) for minimum tripping (17):

- anti-clockwise to decrease the slam-shut device tripping pressure;
- clockwise to increase the slam-shut device tripping pressure.

 **NOTICE!**

For calibration ranges, please refer to chapter “13 - Flow rate tables”.

9 - MAINTENANCE AND FUNCTIONAL CHECKS

9.1 - GENERAL WARNINGS

HAZARD!

- Maintenance work must be carried out by qualified personnel trained on safety in the workplace and authorised to carry out equipment-related activities.
- Each maintenance operation requires in-depth and specialised knowledge of the equipment, the necessary operations, the associated risks and the correct procedures to operate safely.
- Repair or maintenance work not provided for in this manual may be carried out only if approved by PIETRO FIORENTINI S.p.A.. PIETRO FIORENTINI S.p.A. shall not be held liable for damage to persons or property resulting from operations other than those described herein or carried out in ways other than as indicated.

WARNING!

Before conducting any work, make sure that the line on which the equipment is installed:

- has been shut off downstream and upstream;
- has been discharged.

WARNING!

In case of doubt, do not perform any work. Contact PIETRO FIORENTINI S.p.A. for the necessary clarifications.

The management and/or use of the equipment includes interventions that are necessary as a result of normal use such as:

- inspection and checks;
- functional checks;
- routine maintenance;
- special maintenance.

NOTICE!

Maintenance work is strictly related to:

- the quality of the conveyed gas (impurities, humidity, gasoline, corrosive substances);
- the effectiveness of filtration;
- the equipment conditions of use.

To properly run the equipment, one should:

- follow the service frequency referred to in the manual for functional checks and routine maintenance.
- not exceed the time interval between one service and the next. The time interval is to be understood as the maximum acceptable; it can, however, be shortened;
- promptly check the causes of any anomalies such as excessive noise, leakage of fluids or similar and remedy them. The timely removal of any causes of anomaly and/or malfunction prevents further damage to the equipment and ensures operator safety;

Before beginning disassembly of the equipment, make sure that:

- the spare parts and parts used in replacements have adequate requirements to ensure the original performance of the equipment. Use original, compliant spare parts;
- the operator must have the necessary equipment (see chapter “7 - Commissioning/maintenance equipment”).

! NOTICE!

The recommended spare parts are unambiguously identified with tags indicating:


- **the assembly drawing number of the equipment where they are installed (see Chapter “12 - Recommended spare parts”);**
- **the position specified in the assembly drawing of the equipment.**

The equipment maintenance operations are divided, from an operational point of view, into three main categories:

| Commissioning and maintenance operations | |
|--|--|
| Periodic checks and inspections | All those checks that the operator must carry out on a regular basis to ensure that the equipment is in proper working order. |
| Routine maintenance | All those operations that the operator must preventively carry out to ensure proper operation of the device over time. Routine maintenance includes: <ul style="list-style-type: none"> • inspection; • control; • adjustment; • cleaning; • lubrication; • replacement; of all spare parts. |
| Special maintenance | All those operations to be carried out by the operator when the equipment requires them. |

Tab. 9.57

9.2 - PERIODICALLY CHECKING AND INSPECTING THE EQUIPMENT FOR PROPER OPERATION

| Periodic checks and inspections | |
|---------------------------------|---|
| Operator qualification | Mechanical maintenance technician |
| PPE required |  <p>WARNING!</p> <p>The PPE listed in this table is related to the risk associated with the equipment. For the PPE required to protect against risks associated with the workplace, installation or operating conditions, please refer to:</p> <ul style="list-style-type: none"> the regulations in force in the country of installation; any information provided by the Safety Manager at the installation facility. |

Tab. 9.58

“Tab. 9.59” lists checks and verifications, i.e. operations that do not require any manual intervention on the individual equipment.

Some items thereof can be replaced remotely using suitable remote control tools. The following is listed below:

| Activity description | Equipment/accessories involved | Evaluation criterion | Minimum frequency |
|---|--|---|-------------------|
| Significant performance check* | Pressure regulators | <ul style="list-style-type: none"> No fluctuations in the adjusted pressure. Significant pressure values within pre-set limits. | Monthly |
| | Gas flow slam-shut type safety devices (external position indicator) | <ul style="list-style-type: none"> Fully open position. | |
| | Stand-by monitor (external position indicator) | <ul style="list-style-type: none"> Fully open position. | |
| Visual inspection of the equipment outside condition | All | <ul style="list-style-type: none"> No visible damage. External surface protection as per UNI 9571-1:2012. | Half-yearly |

Tab. 9.59

* These checks may be carried out remotely if there is a remote control system capable of analysing the significant performance of the equipment and of sending alerts/alarms when pre-set thresholds are reached.

9.3 - ROUTINE MAINTENANCE

9.3.1 - GENERAL SAFETY WARNINGS

 **HAZARD!**

- Put the equipment in a safe condition (close the downstream shut-off valve and then the upstream one, and drain the line completely);
- ensure that the pressure upstream and downstream of the equipment is “0”.

 **NOTICE!**

Before installing new sealing elements (o-rings, diaphragm, etc.), they must be checked for integrity.

9.3.2 - REPLACEMENT FREQUENCY FOR COMPONENTS SUBJECT TO WEAR

NOTICE!

The following provisions shall apply to equipment components only.

The non-metallic parts of the equipment concerned are divided into the following two categories:

Preventive maintenance work

| | |
|-------------------|---|
| Category 1 | Parts subject to wear and/or abrasion, where: <ul style="list-style-type: none"> wear and tear means the normal degradation of a part after prolonged use under normal operating conditions; abrasion is the mechanical action on the surface of the affected part resulting from the passage of gas under normal operating conditions. |
| Category 2 | Parts subject to aging only, including parts that also require lubrication and/or cleaning. |

Tab. 9.60

NOTICE!

Check, within the minimum frequency specified in “Tab. 9.61”, the available components for wear/abrasion/aging.


| Category | Part description | Evaluation criterion | Minimum replacement frequency |
|----------|--|---|-------------------------------|
| 1 | Valve seat sealing rings and non-metallic plugs | Pressure regulators | 6 years |
| | | Safety devices | |
| | | Pressure safety system equipment | |
| 1 | Non-metallic parts with internal sealing function of valve seats and accessories of individual equipment | Pilots | 6 years |
| | | Pre-regulators | |
| | | Accelerators | |
| | | Any others | |
| 1 | Non-metallic parts with a sealing function between parts, at least one of which is in motion under normal working/operating conditions | Pressure regulators | 6 years |
| | | Gas flow slam-shut type safety devices | |
| | | Relief devices with discharge to atmosphere | |
| 1 | Non-metallic parts with sealing function involved in disassembly operations during maintenance | Equipment subject to maintenance | 6 years |
| 2 | Non-metallic parts providing feedback (sensing elements) of the controlled pressure of safety equipment | Safety equipment and/or accessories | 6 years |
| 2 | Non-metallic parts with sealing and performance functions (diaphragms) of equipment | Pressure regulators and accessories | 6 years |
| | | Gas flow slam-shut type safety devices | 6 years |
| | | Relief device with discharge to atmosphere | 6 years |
| 2 | Non-metallic parts of equipment with an internal sealing function: under normal operating conditions during maintenance | Relief valves | 6 years |
| | | Regulation lines disconnection equipment | If there are proven leaks |
| 2 | Non-metallic parts with a static sealing function only | Various equipment | If there are proven leaks |

DIVAL 700

| Category | Part description | Evaluation criterion | Minimum replacement frequency |
|----------|-------------------|----------------------|-------------------------------|
| 2 | Lubricating parts | Shut-off valves | Yearly |
| | | Other equipment | Yearly |
| 2 | Filter elements | Filters | As needed |

Tab. 9.61

9.4 - ROUTINE MAINTENANCE PROCEDURES

| Routine maintenance | |
|------------------------|--|
| Operator qualification | Operator qualification |
| PPE required |  <p>WARNING!</p> <p>The PPE listed in this table is related to the risk associated with the equipment. For the PPE required to protect against risks associated with the workplace, installation or operating conditions, please refer to:</p> <ul style="list-style-type: none"> • the regulations in force in the country of installation; • <u>any information provided by the Safety Manager at the installation facility.</u> |
| Equipment required | Please refer to the chapter “7 - Commissioning/maintenance equipment”. |

Tab. 9.62

9.4.1 - TIGHTENING TORQUES

9.4.1.1 - TIGHTENING TORQUES FOR DIVAL 700 REGULATOR




Fig. 9.25. Tightening torques DIVAL 700

DIVAL 700 1" ; 1" ½; 2" - BP, MP, TR HEADS

| Pos. | Description | Torque (Nm) | Torque (ft - lb) |
|------|----------------------|-------------|------------------|
| 2 | Valve seat | 50 | 36 |
| 4 | Screw M5x14 UNI 5931 | 4 | 2 |
| 48 | Screw M5x12 UNI 8111 | 4 | 2 |
| 103 | Screw M8X25 UNI 5931 | 14 | 10 |
| 324 | Fixing nut | 14 | 10 |
| 332 | Fixing nut | 4 | 2 |
| 360 | Screw M6x50 DIN 6921 | 9 | 6 |

Tab. 9.63

9.4.1.2 - TIGHTENING TORQUES OF REGULATOR WITH MONITOR FUNCTION




Fig. 9.26. Regulator with monitor function tightening torques

DIVAL 700 WITH MONITOR FUNCTION

| Pos. | Description | Torque (Nm) | Torque (ft - lb) |
|------|----------------------|-------------|------------------|
| 2 | Valve seat | 50 | 36 |
| 4 | Screw M5x14 UNI 5931 | 4 | 2 |
| 48 | Screw M5x12 UNI 8111 | 4 | 2 |
| 103 | Screw M8X25 UNI 5931 | 14 | 10 |
| 324 | Fixing nut | 14 | 10 |
| 332 | Fixing nut | 4 | 2 |
| 360 | Screw M6x50 DIN 6921 | 9 | 6 |

Tab. 9.64

9.4.1.3 - TIGHTENING TORQUE LA SLAM-SHUT VALVE




Fig. 9.27. LA Slam-shut valve tightening torques

LA 1" ; 1" ½; 2 - BP, MP, TR HEADS

| Pos. | Description | Torque (Nm) | Torque (ft - lb) |
|-------------|----------------------|--------------------|-------------------------|
| 505 | Rod guide | 4.5 | 3.3 |
| 511 | TSC M5X20 TORX screw | 2.5 | 1.8 |
| 513 | M4 nut UNI 5588 | 1.5 | 0.8 |
| 521 | TGS M4X27 TORX screw | 4.5 | 3.3 |
| 625 | Screw M5X14 | 4 | 3 |
| 628 | Locking nut | 1.5 | 1.1 |
| 632 | Bushing | 1.5 | 1.1 |

Tab. 9.65

9.4.2 - REPLACING ELEMENTS SUBJECT TO WEAR AND ABRASION

9.4.2.1 - INITIAL OPERATIONS

ATTENTION!

Before carrying out any work, it is important to ensure that the line on which the regulator is installed has been shut off upstream and downstream, and discharged.

ATTENTION!

During assembly, make sure to tighten the screws as per the tables (tightening torques), according to the size for which maintenance is being carried out.

Proceed as follows:

| Step | Action |
|------|--|
| 1 | Unscrew the conical fittings to disconnect all power sockets and sensing lines of the regulator. |

Tab. 9.66

9.4.2.2 - CROSS DIAGRAM FOR TIGHTENING SCREWS

To tighten the screws, when required by the maintenance procedure, refer to the following diagram:




Fig. 9.28. Cross diagram

9.4.3 - REGULATOR MAINTENANCE PROCEDURE DIVAL 700

9.4.3.1 - DIVAL 700 REGULATOR BP/MP HEADS






Fig. 9.29. DIVAL 700 Regulator BP/MP heads

| Step | Action |
|------|---|
| 1 | Unscrew and remove the cap (354). |
| 2 | Remove the O-ring (353) and replace it, taking care to lubricate it with synthetic grease. <div style="border: 1px solid blue; padding: 2px;">! NOTICE!</div> Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution. |
| 3 | Unscrew and remove the ring nut (351) together with the washer (352). <div style="border: 1px solid blue; padding: 2px;">! NOTICE!</div> Turn the ring nut anti-clockwise. |
| 4 | Remove the regulation spring (328). |
| 5 | Unscrew and remove the screws (103) securing the control head (A) to the body (C). |
| 6 | Remove the control head (A) together with the plug assembly (B). |
| 7 | Separate the plug assembly (B) from the control head (A). <div style="border: 1px solid blue; padding: 2px;">! NOTICE!</div> Follow the direction of the arrow on the lower cover (310). |
| 8 | Unscrew and remove the nuts (361). |
| 9 | Undo and remove the screws (360). |
| 10 | Remove the upper cover (340) from the lower cover (310). |
| 11 | Unscrew and remove the locking nut (332). |
| 12 | Pull out the spring (331) of the relief valve. |
| 13 | Pull the diaphragm support assembly (321, 322, 323, 324) off the rod (302). |
| 14 | Remove the O-ring (303) and replace it, taking care to lubricate it with synthetic grease. <div style="border: 1px solid blue; padding: 2px;">! NOTICE!</div> Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution. |
| 15 | Unscrew and remove the locking nut (324). <div style="border: 1px solid blue; padding: 2px;">! NOTICE!</div> During this phase, keep the diaphragm support (323) still. |
| 16 | Remove the diaphragm protection disc (322). |
| 17 | Remove and replace the main diaphragm (321). |
| 18 | Fit the diaphragm protection disc (322). |
| 19 | Insert and secure the locking nut (324), according to the tightening torques: <ul style="list-style-type: none"> • “Tab. 9.63” <div style="border: 1px solid blue; padding: 2px;">! NOTICE!</div> During this phase, keep the diaphragm support (323) still. |
| 20 | Position the diaphragm support assembly (321, 322, 323, 324, 390) in the rod (302). |
| 21 | Insert the spring (331) of the relief valve. |





DIVAL 700 Regulator BP/MP heads

| Step | Action |
|------|--|
| 22 | Insert and fix the nut (332) according to the following tightening torques: <ul style="list-style-type: none"> • “Tab. 9.63” |
| 23 | Place the upper cover (340) on the lower cover (310). <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>! NOTICE!</p> <p>Follow the orientation of the anti-pumping valve when positioning the cover.</p> </div> |
| 24 | Insert and fix the screws (360) together with the nuts (361) according to the following tightening torques: <ul style="list-style-type: none"> • “Tab. 9.63” <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>! NOTICE!</p> <p>Screw in as shown in the diagram at “9.4.2.2 - Cross diagram for tightening screws”.</p> </div> |
| 25 | Remove the O-ring (213) and replace it, taking care to lubricate it with synthetic grease. <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>! NOTICE!</p> <p>Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution.</p> </div> |
| 26 | Pull the plug holder (208) and plug (211) off the stem (203). |
| 27 | Remove and replace the plug (211) from the plug holder (208). |
| 28 | Place the plug holder (208) and plug (211) in the stem (203). |
| 29 | Unscrew and remove the valve seat (2) together with the O-ring (66). |
| 30 | Remove the O-ring (66) and replace it, taking care to lubricate it with synthetic grease. <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>! NOTICE!</p> <p>Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution.</p> </div> |
| 31 | Insert the valve seat (2) together with the O-ring (66) into the body (C) according to the tightening torques: <ul style="list-style-type: none"> • “Tab. 9.63” |
| 32 | Remove the O-ring (69) and replace it, taking care to lubricate it with synthetic grease. <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>! NOTICE!</p> <p>Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution.</p> </div> |
| 33 | Position the plug assembly (B) in the control head (A). <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>! NOTICE!</p> <p>In the opposite direction indicated by the arrow on the lower cover (310).</p> </div> |
| 34 | Position the control head (A) and plug assembly (B) in the body (C). |
| 35 | Insert and fasten the screws (103) that secure the control head (A) to the body (C) according to the tightening torques: <ul style="list-style-type: none"> • “Tab. 9.63” <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>! NOTICE!</p> <p>Screw in as shown in the diagram at “9.4.2.2 - Cross diagram for tightening screws”.</p> </div> |
| 36 | Insert the regulation spring (328). |
| 37 | Insert and secure the adjustment ring nut (351) together with the washer (352). |
| 38 | Insert and secure the plug (354) together with the O-ring (353). |
| 39 | Undo and remove the lower screws (48). |
| 40 | Remove the flange (551) together with the O-ring (65). |



DIVAL 700 Regulator BP/MP heads

| Step | Action |
|------|---|
| 41 | <p>Remove the O-ring (65) and replace it, taking care to lubricate it with synthetic grease.</p> <div style="border: 1px solid blue; padding: 2px;">  NOTICE! Before inserting the replacement O-rings, clean the retaining slots with a cleaning solution. </div> |
| 42 | Position the flange (551) together with the O-ring (65). |
| 43 | <p>Insert and fix the lower screws (48) according to the following tightening torques:</p> <ul style="list-style-type: none"> • “Tab. 9.63” <div style="border: 1px solid blue; padding: 2px;">  NOTICE! Screw in as shown in the diagram at “9.4.2.2 - Cross diagram for tightening screws”. </div> |

Tab. 9.67

 **WARNING!**

Ensure that all parts have been fitted correctly.

9.4.3.2 - DIVAL 700 REGULATOR TR HEAD






Fig. 9.30. DIVAL 700 Regulator TR head

| Step | Action |
|------|--|
| 1 | Unscrew and remove the adjusting screw (609) together with the locking nut (607). |
| 2 | Remove and replace the O-rings (353, 608), taking care to lubricate them with synthetic grease. <div style="border: 1px solid blue; padding: 5px;">NOTICE!</div> Before inserting the replacement O-rings, clean the retaining slots with a cleaning solution. |
| 3 | Remove the spring guide disc (610) together with the washer (352). |
| 4 | Remove the regulation spring (328). |
| 5 | Unscrew and remove the screws (103) securing the control head (A) to the body (C). |
| 6 | Remove the control head (A) together with the plug assembly (B). |
| 7 | Separate the plug assembly (B) from the control head (A). <div style="border: 1px solid blue; padding: 5px;">NOTICE!</div> Follow the indication of the arrow. |
| 8 | Unscrew and remove the nuts (361). |
| 9 | Undo and remove the screws (360). |
| 10 | Remove the upper cover (340) from the lower cover (310). |
| 11 | Unscrew and remove the locking nut (332). |
| 12 | Pull out the spring (331) of the relief valve. |
| 13 | Pull the diaphragm support assembly (321, 322, 323, 324) off the rod (302). |
| 14 | Remove the O-ring (303) and replace it, taking care to lubricate it with synthetic grease. <div style="border: 1px solid blue; padding: 5px;">NOTICE!</div> Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution. |
| 15 | Unscrew and remove the locking nut (324). <div style="border: 1px solid blue; padding: 5px;">NOTICE!</div> During this phase, keep the diaphragm support (323) still. |
| 16 | Remove the spring support (325). |
| 17 | Remove the diaphragm protection disc (322). |
| 18 | Remove and replace the main diaphragm (321). |
| 19 | Position the spring holder (325). |
| 20 | Fit the diaphragm protection disc (322). |
| 21 | Insert and secure the locking nut (324), according to the tightening torques: <ul style="list-style-type: none"> • “Tab. 9.63” <div style="border: 1px solid blue; padding: 5px;">NOTICE!</div> During this phase, keep the diaphragm support (323) still. |
| 22 | Position the diaphragm support assembly (321, 322, 323, 324, 390) in the rod (302). |
| 23 | Insert the spring (331) of the relief valve. |
| 24 | Insert and fix the nut (332) according to the following tightening torques: <ul style="list-style-type: none"> • “Tab. 9.63” |





DIVAL 700 Regulator TR head

| Step | Action |
|------|--|
| 25 | Place the upper cover (340) on the lower cover (310). NOTICE! Follow the orientation of the anti-pumping valve when positioning the cover. |
| 26 | Insert and fix the screws (360) together with the nuts (361) according to the following tightening torques: • “Tab. 9.63” NOTICE! Screw in as shown in the diagram at “9.4.2.2 - Cross diagram for tightening screws”. |
| 27 | Remove the O-ring (213) and replace it, taking care to lubricate it with synthetic grease. NOTICE! Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution. |
| 28 | Pull the plug holder (208) and plug (211) off the stem (203). |
| 29 | Remove and replace the plug (211) from the plug holder (208). |
| 30 | Place the plug holder (208) and plug (211) in the stem (203). |
| 31 | Unscrew and remove the valve seat (2) together with the O-ring (66). |
| 32 | Remove the O-ring (66) and replace it, taking care to lubricate it with synthetic grease. NOTICE! Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution. |
| 33 | Insert the valve seat (2) together with the O-ring (66) into the body (C) according to the tightening torques: • “Tab. 9.63” |
| 34 | Remove the O-ring (69) and replace it, taking care to lubricate it with synthetic grease. NOTICE! Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution. |
| 35 | Position the plug assembly (B) in the control head (A). NOTICE! In the opposite direction indicated by the arrow on the lower cover (310). |
| 36 | Position the control head (A) and plug assembly (B) in the body (C). |
| 37 | Insert and fasten the screws (103) that secure the control head (A) to the body (C) according to the tightening torques: • “Tab. 9.63” NOTICE! Screw in as shown in the diagram at “9.4.2.2 - Cross diagram for tightening screws”. |
| 38 | Insert the regulation spring (328). |
| 39 | Insert the spring guide disc (610) together with washer (352). |
| 40 | Insert and secure the cap (354) together with the O-rings (353, 608). |
| 41 | Insert the adjusting screw (609) together with the locking nut (607) into the cap (354). |
| 42 | Undo and remove the lower screws (48). |



DIVAL 700 Regulator TR head

| Step | Action |
|------|---|
| 43 | Remove the flange (551) together with the O-ring (65). |
| 44 | Remove the O-ring (65) and replace it, taking care to lubricate it with synthetic grease. <div style="border: 1px solid black; padding: 5px;">  NOTICE! Before inserting the replacement O-rings, clean the retaining slots with a cleaning solution. </div> |
| 45 | Position the flange (551) together with the O-ring (65). |
| 46 | Insert and fix the lower screws (48) according to the following tightening torques: <ul style="list-style-type: none"> • “Tab. 9.63” <div style="border: 1px solid black; padding: 5px;">  NOTICE! Screw in as shown in the diagram at “9.4.2.2 - Cross diagram for tightening screws”. </div> |

Tab. 9.68

 **WARNING!**

Ensure that all parts have been fitted correctly.

9.4.4 - LA SLAM-SHUT VALVE

9.4.4.1 - LA SLAM-SHUT VALVE BP/MP HEADS













Fig. 9.31. LA slam-shut valve BP/MP heads

| Step | Action |
|------|--|
| 1 |  ATTENTION! Before servicing, remove the LA slam-shut valve by unscrewing the screws (48) on the regulator (refer to “9.4.3 - Regulator Maintenance Procedure DIVAL 700”). |
| 2 | Unscrew and remove the locking nut (628).  NOTICE! During this step, hold the spacer (626) in place. |
| 3 | Remove and replace the plug (627). |
| 4 | APPLICABLE TO SIZES 1” ½ - 2” ONLY Undo and remove the screws (625). |
| 5 | APPLICABLE TO SIZES 1” ½ - 2” ONLY Remove the flange (623). |
| 6 | APPLICABLE TO SIZES 1” ½ - 2” ONLY Remove the O-ring (624) and replace it, taking care to lubricate it with synthetic grease.  NOTICE! Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution. |
| 7 | Remove the O-ring (622) and replace it, taking care to lubricate it with synthetic grease.  NOTICE! Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution. |
| 8 | Unscrew and remove the cap (509). |
| 9 | Remove the cap (516). |
| 10 | Unscrew and remove the locking nut (513). |
| 11 | Remove the bushing (632).  NOTICE! During this phase, keep the rod (504) still. |
| 12 | Slide the rod (504) in the direction of the reset. |
| 13 | Pull off the knob (506).  NOTICE! During this phase, keep the rod (504) still. |
| 14 | Unscrew and remove the rod guide (505) together with the O-rings (537, 538, 539). |
| 15 | Replace the O-rings (537, 538, 539), lubricating them with synthetic grease.  NOTICE! Before inserting the replacement O-rings, clean the retaining slots with a cleaning solution. |
| 16 | Insert the rod guide (505) together with the O-rings (537, 538, 539), according to the tightening torques: <ul style="list-style-type: none"> • “Tab. 9.65” |
| 17 | Insert and secure the knob (506). |
| 18 | Remove the washer (532). |
| 19 | Remove the rod guide (533) together with O-rings (535, 536, 633). |



LA slam-shut valve BP/MP heads

| Step | Action |
|------|---|
| 20 | Remove and replace the O-rings (535, 536, 633), taking care to lubricate them with synthetic grease. NOTICE! Before inserting the replacement O-rings, clean the retaining slots with a cleaning solution. |
| 21 | Insert rod guide (533) together with O-rings (535, 536, 633). |
| 22 | Fit the washer (532). |
| 23 | Insert the rod (504) in the opposite direction to the reset. |
| 24 | Place the spring (534) in the washer (532). NOTICE! During this phase, keep the rod (504) still. |
| 25 | Position and secure the bushing (632) on the rod (504). |
| 26 | Position and secure the spacer (626). NOTICE! During this step, hold the bushing (632) in place. |
| 27 | Fit the plug (627). |
| 28 | Insert and secure the locking nut (628) according to the tightening torques: • “Tab. 9.65” NOTICE! Apply threadlocker glue |
| 29 | APPLICABLE TO SIZES 1” ½ - 2” ONLY Position the flange (623) in the body (501). |
| 30 | APPLICABLE TO SIZES 1” ½ - 2” ONLY Insert and fix the screws (625) according to the following tightening torques: • “Tab. 9.65” NOTICE! Screw in as shown in the diagram at “9.4.2.2 - Cross diagram for tightening screws”. |
| 31 | Insert and secure the locking nut (513) according to the tightening torques: • “Tab. 9.65” |
| 32 | Position the cap (516). |
| 33 | Insert and fix the cap (509). |
| 34 | Unscrew the cap (546) together with the O-ring (549). |
| 35 | Remove the O-ring (549) and replace it, taking care to lubricate it with synthetic grease. NOTICE! Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution. |
| 36 | Unscrew the adjustment ring nut (545). |
| 37 | Pull out the maximum spring (542). |
| 38 | Remove spring holder (541). |
| 39 | Remove the spring guide (540). NOTICE! If fitted, remove the minimum spring (543). |



LA slam-shut valve BP/MP heads

| Step | Action |
|------|--|
| 40 | Unscrew and remove the screws (510) together with the nuts (511). |
| 41 | Remove the cover (550) from the body (501). |
| 42 | Remove the diaphragm assembly: diaphragm (547), diaphragm protection disc (502), washer (519), diaphragm support (518), compression bushing (520), locking screw (521). |
| 43 | Undo and remove the locking screw (521). NOTICE! During this phase, keep the diaphragm support (518) still. |
| 44 | Unscrew and remove the compression bushing (520). |
| 45 | Remove the washer (519). |
| 46 | Remove the diaphragm protection disc (502). |
| 47 | Replace the diaphragm (547). |
| 48 | Fit the diaphragm protection disc (502). |
| 49 | Position washer (519). |
| 50 | Set compression bushing (520). |
| 51 | Insert and secure the clamping screw (521) in the diaphragm holder, according to the tightening torques: • “Tab. 9.65” |
| 52 | Place diaphragm assembly. |
| 53 | Insert cover (550) into body (501). |
| 54 | Insert and fix the screws (510) together with the nuts (511) according to the tightening torques: • “Tab. 9.65” NOTICE! Screw in as shown in the diagram at “9.4.2.2 - Cross diagram for tightening screws”. |
| 55 | Insert spring guide (540). |
| 56 | Insert spring holder (541). |
| 57 | Insert the maximum spring (542). |
| 58 | Insert and fasten adjustment ring nut (545) |
| 59 | Insert and secure the cap (546) together with the O-ring (549). |
| 60 | ATTENTION! After maintenance, insert the LA slam-shut valve by fastening the screws (48) of the regulator (par. 9.4.3), according to the tightening torques • “Tab. 9.65” NOTICE! Screw in as shown in the diagram at “9.4.2.2 - Cross diagram for tightening screws”. |

Tab. 9.69

WARNING!

Ensure that all parts have been fitted correctly.

9.4.4.2 - LA SLAM-SHUT VALVE TR HEADS














Fig. 9.32. LA slam-shut valve TR heads

| Step | Action |
|------|--|
| 1 |  ATTENTION! Before servicing, remove the LA slam-shut valve by unscrewing the screws (48) on the regulator (refer to “9.4.3 - Regulator Maintenance Procedure DIVAL 700”). |
| 2 | Unscrew and remove the locking nut (628).  NOTICE! During this step, hold the spacer (626) in place. |
| 3 | Remove and replace the plug (627). |
| 4 | APPLICABLE TO SIZES 1” ½ - 2” ONLY Undo and remove the screws (625). |
| 5 | APPLICABLE TO SIZES 1” ½ - 2” ONLY Remove the flange (623). |
| 6 | APPLICABLE TO SIZES 1” ½ - 2” ONLY Remove the O-ring (624) and replace it, taking care to lubricate it with synthetic grease.  NOTICE! Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution. |
| 7 | Remove the O-ring (622) and replace it, taking care to lubricate it with synthetic grease.  NOTICE! Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution. |
| 8 | Unscrew and remove the cap (509). |
| 9 | Remove the cap (516). |
| 10 | Unscrew and remove the locking nut (513). |
| 11 | Remove the bushing (632).  NOTICE! During this phase, keep the rod (504) still. |
| 12 | Slide the rod (504) in the direction of the reset. |
| 13 | Unscrew and remove the knob (506).  NOTICE! During this phase, keep the rod (504) still. |
| 14 | Unscrew and remove the rod guide (505) together with the O-rings (537, 538, 539). |
| 15 | Replace the O-rings (537, 538, 539), lubricating them with synthetic grease.  NOTICE! Before inserting the replacement O-rings, clean the retaining slots with a cleaning solution. |
| 16 | Insert rod guide (505) together with O-rings (537, 538, 539). |
| 17 | Insert and secure the knob (506). |
| 18 | Remove the washer (532). |
| 19 | Remove the rod guide (533) together with O-rings (535, 536, 633). |






LA slam-shut valve TR header

| Step | Action |
|------|--|
| 20 | Remove and replace the O-rings (535, 536, 633), taking care to lubricate them with synthetic grease. <div style="border: 1px solid black; padding: 2px;">  NOTICE! Before inserting the replacement O-rings, clean the retaining slots with a cleaning solution. </div> |
| 21 | Insert rod guide (533) together with O-rings (535, 536, 633). |
| 22 | Fit the washer (532). |
| 23 | Insert the rod (504) in the opposite direction to the reset. |
| 24 | Place the spring (534) in the washer (532). <div style="border: 1px solid black; padding: 2px;">  NOTICE! During this phase, keep the rod (504) still. </div> |
| 25 | Position and secure the bushing (632) on the rod (504). |
| 26 | Position and secure the spacer (626). <div style="border: 1px solid black; padding: 2px;">  NOTICE! During this step, hold the bushing (632) in place. </div> |
| 27 | Fit the plug (627). |
| 28 | Insert and secure the locking nut (628) according to the tightening torques: <ul style="list-style-type: none"> • “Tab. 9.65” <div style="border: 1px solid black; padding: 2px;">  NOTICE! Apply threadlocker glue </div> |
| 29 | APPLICABLE TO SIZES 1” ½ - 2” ONLY Position the flange (623) in the body (501). |
| 30 | APPLICABLE TO SIZES 1” ½ - 2” ONLY Insert and fix the screws (625) according to the following tightening torques: <ul style="list-style-type: none"> • “Tab. 9.65” <div style="border: 1px solid black; padding: 2px;">  NOTICE! Screw in as shown in the diagram at “9.4.2.2 - Cross diagram for tightening screws”. </div> |
| 31 | Insert and secure the locking nut (513) according to the tightening torques: <ul style="list-style-type: none"> • “Tab. 9.65” |
| 32 | Position the cap (516). |
| 33 | Insert and fix the cap (509). |
| 34 | Unscrew the cap (546) together with the O-ring (549). |
| 35 | Remove the O-ring (549) and replace it, taking care to lubricate it with synthetic grease. <div style="border: 1px solid black; padding: 2px;">  NOTICE! Before inserting the replacement O-ring, clean the retaining slots with a cleaning solution. </div> |
| 36 | Unscrew the adjustment ring nut (545). |
| 37 | Pull out the maximum spring (542). |
| 38 | Remove spring holder (541). |
| 39 | Remove the spring guide (540). <div style="border: 1px solid black; padding: 2px;">  NOTICE! If fitted, remove the minimum spring (543). </div> |



LA slam-shut valve TR header

| Step | Action |
|------|---|
| 40 | Unscrew and remove the screws (510) together with the nuts (511). |
| 41 | Remove the cover (550) from the body (501). |
| 42 | Remove the diaphragm assembly: diaphragm (547), diaphragm protection disc (502), washer (519), diaphragm support (518), compression bushing (520), locking screw (521). |
| 43 | Undo and remove the locking screw (521). <div style="border: 1px solid blue; padding: 5px; margin-top: 5px;">  NOTICE! During this phase, keep the diaphragm support (518) still. </div> |
| 44 | Unscrew and remove the compression bushing (520). |
| 45 | Remove the washer (519). |
| 46 | Remove the diaphragm protection disc (502). |
| 47 | Replace the diaphragm (547). |
| 48 | Fit the diaphragm protection disc (502). |
| 49 | Position washer (519). |
| 50 | Set compression bushing (520). |
| 51 | Insert and secure the clamping screw (521) in the diaphragm holder, according to the tightening torques: <ul style="list-style-type: none"> • “Tab. 9.65” |
| 52 | Place diaphragm assembly. |
| 53 | Insert cover (550) into body (501). |
| 54 | Insert and fix the screws (510) together with the nuts (511) according to the tightening torques: <ul style="list-style-type: none"> • “Tab. 9.65” |
| 55 | Insert spring guide (540). |
| 56 | Insert spring holder (541). |
| 57 | Insert the maximum spring (542). |
| 58 | Insert and fasten adjustment ring nut (545) |
| 59 | Insert and secure the cap (546) together with the O-ring (549). |
| 60 | <div style="background-color: yellow; padding: 5px; margin-bottom: 5px;">  ATTENTION! After maintenance, insert the LA slam-shut valve by fastening the screws (48) of the regulator (par. 9.4.3), according to the tightening torques <ul style="list-style-type: none"> • “Tab. 9.65” </div> <div style="border: 1px solid blue; padding: 5px; margin-top: 5px;">  NOTICE! Screw in as shown in the diagram at “9.4.2.2 - Cross diagram for tightening screws”. </div> |

Tab. 9.70

 **WARNING!**

Ensure that all parts have been fitted correctly.

9.4.6 - PROCEDURE FOR RECOMMISSIONING AFTER MAINTENANCE

 **NOTICE!**

For the re-commissioning procedure, please follow the instructions in section “8.5 - Regulator commissioning procedure”

10 - TROUBLESHOOTING

Listed below are the cases (causes and tripping) that could occur in the form of malfunctions of various kinds over time. These situations depend on the conditions of the gas as well as on the natural ageing and wear of the materials.

10.1 - GENERAL WARNINGS

HAZARD!

Maintenance work must be carried out by qualified personnel:

- trained on workplace safety also based on the regulations in force in the place of installation of the work equipment;
- qualified and authorised to carry out activities related to the equipment.

WARNING!







PIETRO FIORENTINI S.p.A. shall not be held liable for any damage to people and property due to services:

- other than those described;
- performed according to methods other than those specified;
- carried out by unsuitable personnel.

NOTICE!

If an operating fault occurs and qualified personnel are not available for the specific service, call the PIETRO FIORENTINI S.p.A. Authorised Assistance Centre

10.2 - OPERATOR QUALIFICATION SPECIFICATION

| Commissioning | |
|-------------------------------|--|
| Operator qualification | <ul style="list-style-type: none"> • Mechanical maintenance technician; • Electrical maintenance technician; • Installer; • Name of the user. |
| PPE required | <div style="display: flex; align-items: center; gap: 10px;">      </div> <div style="background-color: #f4a460; padding: 5px; margin-top: 5px;">  WARNING! </div> <p>The PPE listed in this table is related to the risk associated with the equipment. For the PPE required to protect against risks associated with the workplace, installation or operating conditions, please refer to:</p> <ul style="list-style-type: none"> • the regulations in force in the country of installation; • <u>any information provided by the Safety Manager at the installation facility.</u> |
| Equipment required | Please refer to the chapter “7 - Commissioning/maintenance equipment”. |

Tab. 10.71

10.3 - TROUBLESHOOTING PROCEDURES

For proper troubleshooting, proceed as follows:

- close the downstream shut-off valves;
- refer to the troubleshooting tables listed below.

10.4 - TROUBLESHOOTING TABLES

NOTICE!

See chapter “9 - Maintenance and functional checks” for pictures of the regulator DIVAL 700 and its accessories.

10.4.1 - TROUBLESHOOTING DIVAL 700 REGULATOR

| Failure | Possible causes | Intervention |
|--|--|-----------------------------|
| Failed sealing or zero flow rate | Valve seat (2) damaged | Replace |
| | Plug (211) damaged | Replace |
| | O-ring (202) damaged | Replace |
| | O-ring (213) damaged | Replace |
| | O-ring (215) damaged | Replace |
| | Diaphragm (209) damaged | Replace |
| | Dirt or presence of foreign bodies in the sealing area | Clean |
| Pumping | Plug rod assembly friction | Clean and replace if needed |
| | Blocked anti-pumping valves | Clean and replace if needed |
| | Reduced downstream volumes | Increase the volume |
| Downstream pressure increases on delivery | Broken or damaged diaphragm (321) | Replace |
| | Broken or damaged diaphragm (209) | Replace |

Tab. 10.72

10.4.2 - LA SLAM-SHUT VALVE TROUBLESHOOTING

| Failure | Possible causes | Intervention |
|--|---------------------------------|--------------------------------|
| Slam-shut valve failed to trip | Rod (501) locked in opening | Clean and reposition if needed |
| External leak | Broken diaphragm (517) | Replace |
| Downstream pressure (Pd) increases in open valve position | O-ring (521) not sealing | Replace |
| | O-ring (523) not sealing | Replace |
| | Rod (501) damaged | Replace |
| Downstream pressure (Pd) increases in closed valve position | O-ring (521) not sealing | Replace |
| | Rod (501) damaged | Replace |
| | Reinforced gasket (528) damaged | Replace |
| | Valve seat (102) damaged | Replace |
| | Damaged valve seat O-ring (104) | Replace |
| Slam-shut valve failed to trip due to pressure increase | Broken diaphragm (517) | Replace |
| Slam-shut valve failed to trip due to pressure decrease | Broken diaphragm (517) | Replace |

Tab. 10.73

11 - UNINSTALLATION AND DISPOSAL

11.1 - GENERAL SAFETY WARNINGS

HAZARD!



Make sure that there are no potentially explosive ignition sources in the work area set up to uninstall and/or dispose of the equipment.

WARNING!

Before proceeding with uninstallation and disposal, make the equipment safe by disconnecting it from any power supply.

11.2 - QUALIFICATION OF THE OPERATORS IN CHARGE

Commissioning

| | |
|------------------------|---|
| Operator qualification | Installer |
| PPE required |  <p> WARNING!</p> <p>The PPE listed in this table is related to the risk associated with the equipment. For the PPE required to protect against risks associated with the workplace, installation or operating conditions, please refer to:</p> <ul style="list-style-type: none"> • the regulations in force in the country of installation; • any information provided by the Safety Manager at the installation facility. |
| Equipment required | Please refer to the chapter “7 - Commissioning/maintenance equipment”. |

Tab. 11.74

11.3 - UNINSTALLATION

ATTENTION!

Before uninstalling the equipment, completely drain the fluid in the reduction line and inside the equipment.

NOTICE!

For equipment uninstallation procedures, please refer to the installation procedures (see chapter “6 - installation”), proceeding in reverse order.

11.4 - INFORMATION REQUIRED IN CASE OF RE-INSTALLATION

NOTICE!

Should the equipment be reused after uninstallation, refer to chapters:

- “6 - installation”;
- “8 - Commissioning”.

11.5 - DISPOSAL INFORMATION

NOTICE!

Bear in mind that the laws in force in the country of installation must be complied with. Illegal or improper disposal involves the application of the penalties provided for by the legislation in force in the country of installation.

NOTICE!

Proper disposal prevents damage to humans and the environment and promotes the reuse of precious raw materials.

The equipment was manufactured with materials that can be recycled by specialised companies. For proper disposal of the equipment, proceed as specified in “Tab. 11.75”:

| Step | Action |
|------|---|
| 1 | Set up a large work area free from obstacles where to safely dismantle the equipment. |
| 2 | Sort the various components by type of material for easier recycling through separate collection. |
| 3 | Send the materials obtained in Step 2 to a specialised company. |

Tab. 11.75

The equipment in any configuration consists of the following materials:

| Material | Disposal/recycling indications |
|--------------------------------------|---|
| Plastic | It must be dismantled and disposed of separately. |
| Lubricants/Oils | They must be collected and delivered to the appropriate specialised and authorised collection and disposal centres. |
| Steel/Cast Iron | Disassemble and collect separately. It must be recycled through the specific collection centres. |
| Stainless steel | Disassemble and collect separately. It must be recycled through the specific collection centres. |
| Aluminium | Disassemble and collect separately. It must be recycled through the specific collection centres. |
| Pneumatic/electric components | They must be dismantled in order to be reused if they are still in good condition or, if possible, overhauled and recycled. |

Tab. 11.76

NOTICE!

Please refer to the chapter “9 - Maintenance and functional checks” to better identify the composition of the equipment and its parts.

12 - RECOMMENDED SPARE PARTS

12.1 - GENERAL WARNINGS

NOTICE!

If non-original spare parts are used, PIETRO FIORENTINI S.p.A. their declared performance cannot be guaranteed.

It is recommended to use original spare parts PIETRO FIORENTINI S.p.A.

PIETRO FIORENTINI S.p.A. shall not be held liable for any damage caused by using non-original parts.

12.2 - HOW TO REQUEST SPARE PARTS

NOTICE!

For specific information, please refer to the sales network of PIETRO FIORENTINI S.p.A.

13 - FLOW RATE TABLES

13.1 - FLOW RATE TABLES

| Dival 700 1/4 BP 1" (AC = 10 according to EN 334) | | | | | |
|---|--------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,02 bar | 0,05 bar | 0.1 bar | 0.2 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 30 | 30 | 30 | 30 | 25 |
| 1.0 | 45 | 45 | 45 | 43 | 40 |
| 2.0 | 73 | 73 | 73 | 73 | 72 |
| 3.0 | 100 | 100 | 95 | 100 | 100 |
| 4.5 | 129 | 137 | 139 | 139 | 139 |
| 6.0 | 149 | 179 | 179 | 179 | 179 |
| 8.5 | 83 | 98 | 122 | 165 | 226 |

C_g = 50 | K₁ = 98

Tab. 13.77

| Dival 700 1/4 BP 1' ½ (AC = 10 according to EN 334) | | | | | |
|---|--------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,02 bar | 0,05 bar | 0.1 bar | 0.2 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 30 | 30 | 30 | 28 | 25 |
| 1.0 | 45 | 45 | 45 | 43 | 40 |
| 2.0 | 73 | 73 | 73 | 73 | 72 |
| 3.0 | 100 | 100 | 100 | 100 | 100 |
| 4.5 | 139 | 139 | 139 | 139 | 139 |
| 6.0 | 179 | 179 | 179 | 175 | 162 |
| 8.5 | 226 | 226 | 226 | 225 | 225 |

C_g = 50 | K₁ = 119

Tab. 13.78

| Dival 700 1/4 BP 2" (AC = 10 according to EN 334) | | | | | |
|---|--------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,02 bar | 0,05 bar | 0.1 bar | 0.2 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 30 | 30 | 30 | 32 | 35 |
| 1.0 | 45 | 57 | 45 | 43 | 40 |
| 2.0 | 73 | 73 | 73 | 73 | 72 |
| 3.0 | 100 | 100 | 100 | 100 | 100 |
| 4.5 | 139 | 139 | 139 | 139 | 139 |
| 6.0 | 179 | 179 | 179 | 179 | 179 |
| 8.5 | 226 | 226 | 226 | 225 | 226 |

C_g = 50 | K₁ = 115

Tab. 13.79

Dival 700 3/8 BP 1" (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,02 bar | 0,05 bar | 0.1 bar | 0.2 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 55 | 55 | 60 | 60 | 51 |
| 1.0 | 90 | 90 | 90 | 97 | 104 |
| 2.0 | 136 | 118 | 128 | 136 | 135 |
| 3.0 | 140 | 130 | 149 | 157 | 178 |
| 4.5 | 139 | 179 | 189 | 227 | 249 |
| 6.0 | 149 | 199 | 189 | 253 | 318 |
| 8.5 | 83 | 128 | 198 | 312 | 412 |

C_g = 92 | K₁ = 91
Tab. 13.80
Dival 700 3/8 BP 1" ½ (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,02 bar | 0,05 bar | 0.1 bar | 0.2 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 59 | 56 | 50 | 49 | 55 |
| 1.0 | 100 | 100 | 100 | 96 | 90 |
| 2.0 | 148 | 148 | 147 | 147 | 146 |
| 3.0 | 199 | 199 | 199 | 199 | 199 |
| 4.5 | 294 | 308 | 284 | 290 | 275 |
| 6.0 | 355 | 374 | 378 | 378 | 378 |
| 8.5 | 377 | 414 | 471 | 471 | 471 |

C_g = 107 | K₁ = 101
Tab. 13.81
Dival 700 3/8 BP 2" (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,02 bar | 0,05 bar | 0.1 bar | 0.2 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 90 | 89 | 60 | 64 | 55 |
| 1.0 | 100 | 100 | 100 | 96 | 90 |
| 2.0 | 148 | 148 | 148 | 147 | 146 |
| 3.0 | 219 | 219 | 219 | 219 | 219 |
| 4.5 | 294 | 303 | 284 | 297 | 275 |
| 6.0 | 378 | 412 | 378 | 378 | 378 |
| 8.5 | 471 | 473 | 471 | 471 | 471 |

C_g = 107 | K₁ = 101
Tab. 13.82

| Dival 700 1/2 BP 1" (AC = 10 according to EN 334) | | | | | |
|---|--------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,02 bar | 0,05 bar | 0.1 bar | 0.2 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 95 | 80 | 85 | 85 | 72 |
| 1.0 | 105 | 110 | 120 | 130 | 139 |
| 2.0 | 172 | 156 | 167 | 179 | 237 |
| 3.0 | 189 | 164 | 179 | 187 | 323 |
| 4.5 | 199 | 204 | 206 | 301 | 446 |
| 6.0 | 199 | 199 | 229 | 327 | 538 |
| 8.5 | 198 | 198 | 228 | 356 | 580 |

C_g = 161 | K₁ = 97

Tab. 13.83

| Dival 700 1/2 BP 1" ½ (AC = 10 according to EN 334) | | | | | |
|---|--------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,02 bar | 0,05 bar | 0.1 bar | 0.2 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 90 | 83 | 71 | 66 | 75 |
| 1.0 | 165 | 165 | 165 | 163 | 133 |
| 2.0 | 242 | 239 | 239 | 244 | 236 |
| 3.0 | 269 | 324 | 329 | 340 | 260 |
| 4.5 | 323 | 367 | 428 | 456 | 432 |
| 6.0 | 397 | 469 | 507 | 540 | 547 |
| 8.5 | 425 | 494 | 543 | 599 | 729 |

C_g = 141 | K₁ = 94

Tab. 13.84

| Dival 700 1/2 BP 2" (AC = 10 according to EN 334) | | | | | |
|---|--------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,02 bar | 0,05 bar | 0.1 bar | 0.2 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 128 | 125 | 105 | 80 | 78 |
| 1.0 | 170 | 165 | 165 | 163 | 133 |
| 2.0 | 244 | 244 | 244 | 244 | 236 |
| 3.0 | 269 | 324 | 329 | 311 | 249 |
| 4.5 | 323 | 378 | 435 | 459 | 432 |
| 6.0 | 397 | 457 | 507 | 540 | 547 |
| 8.5 | 528 | 532 | 543 | 611 | 729 |

C_g = 151 | K₁ = 93

Tab. 13.85

Dival 700 3/4 BP 1" (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,02 bar | 0,05 bar | 0.1 bar | 0.2 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 150 | 110 | 110 | 124 | 112 |
| 1.0 | 200 | 130 | 140 | 170 | 205 |
| 2.0 | 247 | 220 | 183 | 230 | 287 |
| 2.5 | 258 | 248 | 196 | 259 | 317 |
| 3.0 | 269 | 269 | 209 | 288 | 346 |
| 4.0 | 299 | 269 | 219 | 331 | 423 |
| 5,0 | 318 | 269 | 234 | 336 | 451 |

C_g = 253 | K₁ = 93
Tab. 13.86
Dival 700 3/4 BP 1" ½ (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,02 bar | 0,05 bar | 0.1 bar | 0.2 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 141 | 134 | 122 | 118 | 136 |
| 1.0 | 181 | 201 | 234 | 236 | 209 |
| 2.0 | 265 | 294 | 342 | 364 | 340 |
| 2.5 | 312 | 346 | 390 | 427 | 395 |
| 3.0 | 360 | 400 | 439 | 490 | 449 |
| 4.0 | 352 | 424 | 508 | 604 | 718 |
| 5,0 | 423 | 509 | 652 | 734 | 863 |

C_g = 158 | K₁ = 96
Tab. 13.87
Dival 700 3/4 BP 2" (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,02 bar | 0,05 bar | 0.1 bar | 0.2 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 218 | 205 | 170 | 147 | 136 |
| 1.0 | 290 | 270 | 275 | 251 | 209 |
| 2.0 | 325 | 318 | 331 | 319 | 274 |
| 2.5 | 417 | 389 | 399 | 385 | 340 |
| 3.0 | 462 | 468 | 423 | 434 | 395 |
| 4.0 | 498 | 548 | 439 | 479 | 449 |
| 5,0 | 520 | 552 | 465 | 535 | 561 |

C_g = 171 | K₁ = 89
Tab. 13.88

| Dival 700 1 BP 1" ½ (AC = 10 according to EN 334) | | | | | |
|---|--------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,05 bar | 0.1 bar | 0.2 bar | 0,3 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 232 | 250 | 228 | 210 | 210 |
| 1.0 | 309 | 340 | 346 | 340 | 340 |
| 2.0 | 383 | 427 | 430 | 417 | 423 |
| 2.5 | 452 | 499 | 507 | 489 | 521 |
| 3.0 | 502 | 527 | 532 | 522 | 541 |
| 4.0 | 548 | 548 | 548 | 548 | 548 |
| 5,0 | 592 | 592 | 592 | 592 | 608 |

C_g = 332 | K₁ = 102

Tab. 13.89

| Dival 700 1 BP 2" (AC = 10 according to EN 334) | | | | | |
|---|--------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,05 bar | 0.1 bar | 0.2 bar | 0,3 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 235 | 250 | 228 | 210 | 210 |
| 1.0 | 315 | 340 | 346 | 340 | 340 |
| 2.0 | 405 | 427 | 430 | 417 | 423 |
| 2.5 | 465 | 499 | 507 | 489 | 521 |
| 3.0 | 531 | 550 | 555 | 545 | 564 |
| 4.0 | 598 | 598 | 598 | 598 | 598 |
| 5,0 | 642 | 642 | 642 | 642 | 642 |

C_g = 346 | K₁ = 86

Tab. 13.90

| Dival 700 1 1/4 BP 1" ½ (AC = 10 according to EN 334) | | | | | |
|---|--------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,05 bar | 0.1 bar | 0.2 bar | 0,3 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 158 | 189 | 242 | 258 | 249 |
| 1.0 | 263 | 286 | 314 | 325 | 322 |
| 2.0 | 290 | 320 | 350 | 375 | 400 |
| 2.5 | 337 | 371 | 402 | 439 | 478 |
| 3.0 | 365 | 401 | 433 | 476 | 529 |
| 4.0 | 404 | 442 | 476 | 525 | 604 |
| 5,0 | 430 | 469 | 504 | 558 | 654 |

C_g = 393 | K₁ = 91

Tab. 13.91

Dival 700 1 1/4 BP 2" (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,05 bar | 0.1 bar | 0.2 bar | 0,3 bar | 0,34 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 250 | 265 | 258 | 240 | 249 |
| 1.0 | 310 | 333 | 325 | 313 | 322 |
| 2.0 | 330 | 350 | 375 | 400 | 400 |
| 2.5 | 373 | 397 | 439 | 478 | 478 |
| 3.0 | 401 | 427 | 476 | 520 | 529 |
| 4.0 | 442 | 473 | 525 | 572 | 604 |
| 5,0 | 469 | 503 | 558 | 607 | 654 |

C_g = 440 | K₁ = 86
Tab. 13.92
Dival 700 1/4 TR 1" (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 30 | - | - | - | - |
| 1.0 | 40 | 40 | 32 | - | - |
| 2.0 | 73 | 72 | 65 | 59 | 56 |
| 3.0 | 100 | 100 | 100 | 100 | 100 |
| 4.5 | 139 | 139 | 139 | 139 | 140 |
| 6.0 | 179 | 179 | 179 | 179 | 179 |
| 8.5 | 226 | 226 | 226 | 226 | 226 |

C_g = 40 | K₁ = 98
Tab. 13.93
Dival 700 1/4 TR 1' 1/2 (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 26 | - | - | - | - |
| 1.0 | 40 | 40 | 32 | - | - |
| 2.0 | 73 | 72 | 65 | 59 | 55 |
| 3.0 | 100 | 100 | 100 | 100 | 100 |
| 4.5 | 139 | 139 | 139 | 139 | 140 |
| 6.0 | 169 | 179 | 179 | 179 | 179 |
| 8.5 | 225 | 226 | 226 | 226 | 226 |

C_g = 50 | K₁ = 119
Tab. 13.94

| Dival 700 1/4 TR 2" (AC = 10 according to EN 334) | | | | | |
|--|------------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 34 | - | - | - | - |
| 1.0 | 40 | 40 | 32 | - | - |
| 2.0 | 73 | 72 | 65 | 59 | 57 |
| 3.0 | 100 | 100 | 100 | 100 | 100 |
| 4.5 | 139 | 139 | 139 | 139 | 140 |
| 6.0 | 179 | 179 | 179 | 179 | 179 |
| 8.5 | 225 | 226 | 226 | 226 | 226 |

Cg = 50 | K1 = 115

Tab. 13.95

| Dival 700 3/8 TR 1" (AC = 10 according to EN 334) | | | | | |
|--|------------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 60 | - | - | - | - |
| 1.0 | 100 | 95 | 91 | - | - |
| 2.0 | 136 | 135 | 120 | 100 | 94 |
| 3.0 | 169 | 179 | 180 | 180 | 180 |
| 4.5 | 249 | 249 | 249 | 249 | 249 |
| 6.0 | 318 | 318 | 318 | 318 | 318 |
| 8.5 | 412 | 412 | 412 | 412 | 412 |

Cg = 93 | K1 = 91

Tab. 13.96

| Dival 700 3/8 TR 1" ½ (AC = 10 according to EN 334) | | | | | |
|--|------------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 55 | - | - | - | - |
| 1.0 | 90 | 80 | 64 | - | - |
| 2.0 | 147 | 145 | 144 | 135 | 131 |
| 3.0 | 199 | 199 | 199 | 200 | 200 |
| 4.5 | 284 | 279 | 291 | 294 | 294 |
| 6.0 | 378 | 378 | 378 | 378 | 378 |
| 8.5 | 471 | 471 | 471 | 471 | 471 |

Cg = 107 | K1 = 101

Tab. 13.97

Dival 700 3/8 TR 2" (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 55 | - | - | - | - |
| 1.0 | 90 | 80 | 64 | - | - |
| 2.0 | 147 | 145 | 144 | 135 | 131 |
| 3.0 | 219 | 219 | 219 | 219 | 220 |
| 4.5 | 284 | 279 | 291 | 294 | 294 |
| 6.0 | 378 | 378 | 378 | 378 | 378 |
| 8.5 | 471 | 471 | 471 | 471 | 471 |

C_g = 109 | K₁ = 104
Tab. 13.98
Dival 700 1/2 TR 1" (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 85 | - | - | - | - |
| 1.0 | 130 | 135 | 127 | - | - |
| 2.0 | 179 | 240 | 233 | 219 | 208 |
| 3.0 | 199 | 319 | 323 | 337 | 339 |
| 4.5 | 435 | 473 | 493 | 523 | 528 |
| 6.0 | 471 | 596 | 636 | 688 | 696 |
| 8.5 | 479 | 737 | 814 | 914 | 931 |

C_g = 180 | K₁ = 97
Tab. 13.99
Dival 700 1/2 TR 1' ½ (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 72 | - | - | - | - |
| 1.0 | 160 | 115 | 103 | - | - |
| 2.0 | 244 | 184 | 206 | 240 | 238 |
| 3.0 | 349 | 319 | 343 | 349 | 349 |
| 4.5 | 428 | 466 | 492 | 498 | 498 |
| 6.0 | 547 | 616 | 640 | 647 | 647 |
| 8.5 | 687 | 785 | 786 | 787 | 787 |

C_g = 170 | K₁ = 94
Tab. 13.100

| Dival 700 1/2 TR 2" (AC = 10 according to EN 334) | | | | | |
|--|------------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 73 | - | - | - | - |
| 1.0 | 160 | 115 | 103 | - | - |
| 2.0 | 244 | 179 | 205 | 195 | 187 |
| 3.0 | 249 | 319 | 343 | 349 | 349 |
| 4.5 | 428 | 488 | 496 | 498 | 498 |
| 6.0 | 547 | 636 | 644 | 647 | 647 |
| 8.5 | 687 | 786 | 786 | 787 | 787 |

Cg = 179 | K1 = 93

Tab. 13.101

| Dival 700 3/4 TR 1" (AC = 10 according to EN 334) | | | | | |
|--|------------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 130 | - | - | - | - |
| 1.0 | 170 | 220 | 204 | - | - |
| 2.0 | 230 | 330 | 338 | 298 | 279 |
| 2.5 | 236 | 376 | 373 | 350 | 346 |
| 3.0 | 239 | 419 | 403 | 399 | 399 |
| 4.0 | 464 | 498 | 498 | 498 | 498 |
| 5,0 | 478 | 597 | 597 | 680 | 697 |

Cg = 317 | K1 = 93

Tab. 13.102

| Dival 700 3/4 TR 1' 1/2 (AC = 10 according to EN 334) | | | | | |
|--|------------------------|--------------------|--------------------|--------------------|--------------------|
| Inlet pressure | Outlet pressure | | | | |
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 125 | - | - | - | - |
| 1.0 | 200 | 240 | 200 | - | - |
| 2.0 | 339 | 389 | 395 | 361 | 344 |
| 2.5 | 395 | 468 | 491 | 479 | 476 |
| 3.0 | 449 | 548 | 588 | 599 | 599 |
| 4.0 | 647 | 797 | 797 | 781 | 778 |
| 5,0 | 796 | 896 | 936 | 946 | 946 |

Cg = 307 | K1 = 91

Tab. 13.103

Dival 700 3/4 TR 2" (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 125 | - | - | - | - |
| 1.0 | 200 | 240 | 200 | - | - |
| 2.0 | 339 | 389 | 395 | 454 | 448 |
| 2.5 | 395 | 468 | 510 | 582 | 594 |
| 3.0 | 449 | 548 | 628 | 711 | 724 |
| 4.0 | 647 | 797 | 797 | 797 | 798 |
| 5,0 | 796 | 896 | 936 | 946 | 946 |

C_g = 320 | K₁ = 89
Tab. 13.104
Dival 700 1 TR 1" ½ (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 210 | - | - | - | - |
| 1.0 | 340 | 330 | 266 | - | - |
| 1.5 | 417 | 426 | 422 | 359 | 282 |
| 2.0 | 489 | 534 | 547 | 507 | 486 |
| 2.5 | 522 | 549 | 576 | 560 | 556 |
| 3.0 | 548 | 548 | 588 | 599 | 599 |
| 3.4 | 592 | 681 | 721 | 709 | 705 |

C_g = 429 | K₁ = 85
Tab. 13.105
Dival 700 1 TR 2" (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 210 | - | - | - | - |
| 1.0 | 340 | 330 | 266 | - | - |
| 1.5 | 417 | 433 | 423 | 359 | 282 |
| 2.0 | 489 | 570 | 555 | 507 | 486 |
| 2.5 | 545 | 593 | 585 | 560 | 556 |
| 3.0 | 598 | 598 | 598 | 599 | 599 |
| 3.4 | 642 | 687 | 722 | 768 | 776 |

C_g = 447 | K₁ = 86
Tab. 13.106

Dival 700 1 1/4 TR 1' 1/2 (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 240 | - | - | - | - |
| 0.8 | 313 | 317 | 0 | - | - |
| 1.0 | 400 | 350 | 326 | - | - |
| 1.3 | 478 | 429 | 398 | 363 | - |
| 1.5 | 520 | 489 | 463 | 457 | 347 |
| 1.8 | 572 | 589 | 577 | 574 | 499 |
| 2.0 | 607 | 655 | 652 | 652 | 633 |

C_g = 530 | K₁ = 85
Tab. 13.107
Dival 700 1 1/4 TR 2" (AC = 10 according to EN 334)

| Inlet pressure | Outlet pressure | | | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 0,03 bar | 0,05 bar | 0,07 bar | 0.1 bar | 0,13 bar |
| bar | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h | Sm ³ /h |
| 0.5 | 240 | - | - | - | - |
| 0.8 | 313 | 317 | 263 | - | - |
| 1.0 | 400 | 350 | 326 | - | - |
| 1.3 | 478 | 429 | 398 | 365 | - |
| 1.5 | 520 | 489 | 463 | 459 | 349 |
| 1.8 | 572 | 589 | 577 | 575 | 499 |
| 2.0 | 607 | 655 | 652 | 652 | 633 |

C_g = 570 | K₁ = 86
Tab. 13.108

TM0023ENG

